



ECpvh

User manual



<b>Document change log</b>	<b>1</b>
<b>Introduction</b>	<b>1</b>
<b>ECweb</b>	<b>6</b>
Connecting to ECweb with Internet Explorer or Pale Moon browser on PC/laptop	6
Connecting to ECweb using any other browser or mobile device	7
Troubleshooting	7
Navigating the ECweb	9
<b>Control</b>	<b>10</b>
IP configuration	10
Internal clock	11
NTP synchronization	11
Manual time adjustment	11
FTP client	11
FTP server	11
Automatic FTP transfer	11
ECpvh server access	11
ECpvh FTP server	12
ECpvh Telnet server	12
ECpvh web server (ECweb)	13
<b>Identifiers</b>	<b>13</b>
ECpvh information	13
Project details	14
Password scheme	15
Passwords	19
Permissions	19
License & Extras	19
Search online	20
Search on USB	20
Metrics	21
Backups	21
Application	22
<b>Settings</b>	<b>23</b>
RS485 COM ports	23
PV	25
Ratings	25
Measurements	26
Reference	31
Ramp rates	33
Ramp threshold	34

Tariff	35
Counters	35
Meter	36
Relay	37
CT settings	38
Frame settings	38
Inverter	39
RTU	39
TCP	41
Advanced Inverter command setup	43
Common inverter command setup	43
SunSpec inverter command setup	43
Secondary inverter setup	44
Multiple inverter cluster setup	44
Inverter PID control	46
Genset	46
References	46
Tariffs	50
Rated sizes	50
Counters	52
Meter	52
Genset management	52
Load dependent start/stop	52
Non-sync.	52
Sync SR.	55
Genset start/stop failures	57
Mains	57
Measurements	57
References	60
API	63
Tariffs	64
Rated sizes	64
Counters	64
Meter	65
Grid support	65
Grid support P(f)	65
Grid support U(Q)	66
Load	67
Load meter for control	69
Sensors	70
Modbus RTU Sensors	70

PV generating capacity	70
IO modules	71
Analogue input/output	71
Alarms	73
Genset low power	74
Mains low power	75
COM2 slave	76
COM3 slave	76
TCP slave	77
Common master communication	78
Modbus Master comm. alarms	79
Overview	79
Nighttime	80
Simulation	80
Proprietary modbus pages	82
<b>Monitoring</b>	<b>83</b>
<b>Logs</b>	<b>85</b>
Local logs with transmission via mail/ftp	86
Log to MySQL database	88
<b>EClogic</b>	<b>89</b>
Builder	89
Example	91
Linker	91
Example continued	92
Overruling of Settings parameters	92
General purpose hysteresis	94
RRCR	95
AIO	95
Sensor	96
IO	96
Command timers	96
Command panel	97
General purpose alarms	97
General purpose timers	98
<b>Monitoring</b>	<b>98</b>
Command panel	103
Sensor data	103
IO module data	104
Simulation	104
PV	104
PV meter data	104


Inverter data	105
Genset	108
Genset meter data	110
Mains	110
Mains meter data	110
Spot price market data	111
Load	111
<b>ECpvh stacking</b>	<b>113</b>
Inverter stacking	113
ECpvH slave	114
ECpvH Master	115
Genset stacking	116
ECpvH slave	118
ECpvH Master	118
<b>Service Tool</b>	<b>119</b>
Identifiers	120
Application	120
Settings	121
Power meter configuration	121
IO configuration	122
AIO	124
Sensor Configuration	125
Modbus Tester	126
Client trace	127
Telnet server	127
<b>Boot</b>	<b>127</b>
Identifiers	128
SW update	128
Application	129

## Document change log

2021-04-27	First version
2021-09-13	Updated after 1.01.0 release
2022-03-23	Updated after 1.04.0 release
2022-08-08	Updated after 1.07.0 release
2022-10-31	Updated after 1.10.0 release
2024-10-18	Updated after 1.12.0 release

## Introduction

The ECpvh from ENcombi is capable of controlling the production of hybrid inverters synchronized to grid and/or gensets. The ECpvh is also capable of controlling PV inverters together with Hybrid inverters. The ECpvh is agnostic in the sense that it integrates with hybrid inverters, PV inverters, gensets, meteorological sensors and power meters independent of vendor and model. A hybrid inverter is in this context defined as a grid following inverter that has battery backup and an UPS load outlet.



The AC production of the inverters are controlled seamlessly via a communication interface to the inverters. This interface can be either via Modbus RTU running on serial RS485 line or via Modbus TCP running on ethernet dependent on the inverter vendor and model used.

The same can be said of the interfaces to genset controller and power meters, these can be interfaced to also via Modbus RTU running on serial RS485 line or via Modbus TCP running on ethernet dependent on the vendors and models used.

Meteorological sensors are interfaced to via Modbus RTU running on serial RS485 line only.

All interfaces for both hybrid inverters, PV inverters, gensets, power sensing meters and meteorological sensors are pre-embedded and are enabled merely by parameter setting.

All configuration and real time monitoring of the ECpvh is done by connecting with a standard web browser to its built in webserver (ECweb). Comprehensive help texts guide you through the configuration setup. The ECweb can run on any device featuring a web browser. Use for instance a panel PC as a local HMI. A laptop or portable device which will give you monitoring and control capabilities even from remote if connectivity to the ECpvh is in place.


It is not mandatory for the control and balancing of the PV, genset and Mains part to work to have HMI or laptop connected to ECweb. It is required for commissioning of the ECpvh only.


Besides doing the control and balancing of the PV, genset and Mains the ECpvh is also acting as a datalogger. The ECpvh can make local file loggings on SD card or USB memory stick. These logs can be sent to the customer ftp server or sent to the customer mail account.

Furthermore the ECpvh can push data to a MySQL server hosted either by ENcombi with ENcombi front-end for data visualization (ECcloud) or customers can choose to push data to their own database and make use of their own data visualization tool.

Data logging functionality and connectivity to the internet is not mandatory for the control and balancing of the PV, genset and Mains part to work.

Below schematics are examples of how ECpvh are fitted into and interconnected to its surrounding environment.





## ECweb

ECweb is the built- in webserver of the ECpvh. All configuration and real time monitoring of the ECpvh is done via ECweb. Connection to ECweb is done with a standard web browser

Using a laptop/PC and Internet Explorer browser running on Java is the best option for connecting to ECweb. Other browsers and mobile devices can be used as well. In this case FireFox browser is recommended.

### Connecting to ECweb with Internet Explorer or Pale Moon browser on PC/laptop

Connecting to ECweb with Internet Explorer or Pale Moon browser on PC/laptop Java from oracle must be installed on PC/laptop. Java can be downloaded from the link below. Note that either the Internet Explorer or the Pale Moon browser must be used for the download.

[Java download](#)

1: Type in IP address of the ECpvh in the browser command line.

Default IP address is:

192.168.1.101.

2: Type in login credentials when prompted.

Default login credentials are:

user: web\_user0

password: web\_password0

3: Accept/Ignore all warnings populated.

4: If tiles on the front page are out of order, click on the page and they will fall into place. If any Icons are missing on the tiles, restart the browser and start over.

### Connecting to ECweb using any other browser or mobile device

For all other browsers on PC/laptop or from any browser on mobile devices.

1: Type in IP address/webvisu.html in the browser command line.

Default IP address is:

192.168.1.101.

2: Type in login credentials when prompted.

Default login credentials are:

user: web\_user0

password: web\_password0

## Troubleshooting

If connection can't be established verify that:

1. ECpvh is powered up and running. ECpvh must have 24VDC (+/- 15%) supply voltage. The green Power and the green Run LEDs in the front of the ECpvh must both be illuminated. Note that a too low supply voltage can result in a situation where sufficient voltage is present to power up the ECpvh but not to run the program. In this case the Power LED is illuminated but the Run LED. When powering up the ECpvh the Power LED will light up first and the Run LED will come approximately 30s after when ECpvh is initialized and the program is up and running.
2. Your laptop must be on the same subnet as the ECpvh. Even though you have an ethernet cable going directly from your laptop to the ECpvh you still need to make sure that your laptop is provided with a suitable IP address. In the case where the default IP address of the ECpvh 192.168.1.101 is kept a suitable IP address for your laptop would be 192.168.1.x, where x is a number in the range [2;249] excluding "101" as this is used by the ECpvh itself.
3. Once the IP of your laptop is in place you must be able to ping the ECpvh. This can be done by opening a command prompt and writing the command "ping xxx.yyy.zzz.www" where xxx.yyy.zzz.www is the IP address of the ECpvh as shown below. First when the ECpvh replies to the command it is verified that your laptop and the ECpvh can see each other on the network and you can connect to ECweb using the browser as described above.


```
C:\Users\Claus>ping 192.168.1.101

Pinging 192.168.1.101 with 32 bytes of data:
Reply from 192.168.1.101: bytes=32 time=15ms TTL=255
Reply from 192.168.1.101: bytes=32 time=25ms TTL=255
Reply from 192.168.1.101: bytes=32 time=1ms TTL=255
Reply from 192.168.1.101: bytes=32 time=11ms TTL=255

Ping statistics for 192.168.1.101:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 1ms, Maximum = 25ms, Average = 13ms
```

## Navigating the ECweb

The first page to be displayed after an initial welcome page when connection is established is the front page of ECweb.



Whenever navigating around the ECweb you can always return to this page by clicking the ENcombi logo in the upper left corner.

In the upper right corner you can see the current access login level. Find more information about this in the chapter revolving password scheme.

In the lower left corner ECpvh will display any info and warning messages it wants to communicate to the user. Some messages will clear themselves automatically. Others demand user action to be acknowledged first. In that case a dedicated button with a garbage can symbol will be presented alongside the messages. Furthermore when changing certain settings etc. a reboot of the ECpvh is required before the changes take effect. This will be communicated in the message as well and a dedicated button with refresh symbol will be presented alongside with the messages.

In the lower right corner is the internal clock of the ECpvh displayed.

In the lower center a total of six menu tiles are available. These are from the left:

1. "Identifiers" gives access to overview of SW version installed and extras present in the ECpvh as well as set up of project details (name, location etc.), password scheme etc.
2. "EClogic" provides the possibility of making project specific logical expressions when required. That could be for linking physical digital inputs applied on power meters to the position of breakers or similar. Also here RRCR can be set up

providing the option of a superior control system to give power references for the ECpvh to follow.

3. "Monitoring" provides a high level overview of the installation as well as detailed information about each individual inverter and power meter.
4. "Control" gives access to set up of ECpvh controller related parameters such as IP configuration, Internal clock handling etc.
5. "Settings" give access to setup of site specific parameters such as number and ratings of genset, grid connections, and inverters, which power meters are used, power and reactive control schemes etc.
6. "Logs" give access to setup of log specific parameters.

In the following chapters the content of the six menu tiles are discussed in detail.

## Control

Under this tile set up of ECpvh controller related parameters for IP configuration, Internal clock handling etc. are found.

### IP configuration

The first page presented when clicking the Control tile is the below page where IP configuration is set up and connectivity to the gateway can be tested.

ENcombi ADMIN

IP config	
IP address:	192.168.1.101
Netmask:	255.255.255.0
Gateway:	192.168.1.1
DNS config	
DNS server 01:	89.249.14.50
DNS server 02:	89.249.14.54

IP setup page.  
Connectivity to gateway and DNS server can be tested.

Test:

2020-07-10-13:10:20

On the right hand side there are four submenus for.

1. Internal clock.
2. Email client.
3. FTP client.
4. ECpvh server access.

### Internal clock

The internal clock can be synchronized against an NTP server as well as be set manually.

#### NTP synchronization

First page presented when clicking the clock button is the page below where NTP synchronization can be set up and connectivity to an NTP server and its functionality can be tested.

### NTP config

NTP address 1: dk.pool.ntp.org  
 NTP address 2: 81.88.24.155  
 UTC: 1  
 Daylight: EUROPEAN  
 NTP sync hour: 0:00  
 NTP: ENABLED



NTP setup page.  
 Connectivity to an NTP server can be tested.

Test:

188.40.88.13



2020-07-10-13:10:47

On the same submenu level the manual time adjustment of the internal clock is found. Clicking the up/down arrows will lead to it.


### Manual time adjustment

On the page below the internal clock can be set manually. The time of the PC connected is presented and can be used to set the ECpvh clock against.

### Manual config

PC time: 2020-07-10-13:11:14

PLC time:



Manual device clock adjustment.  
 PC time shown for reference.

2020-07-10-13:11:12

### FTP client

The ECpvh has an FTP client and can transfer logs to an FTP server. It can be set up to do so automatically in case of event/alarm occurring as well as transferring the summary and production logs when completed. This is discussed in detail in the Logs chapter later in this document. The customer/installer must make use of their own FTP server.

## FTP server

First page presented when clicking the FTP button is the page below where the FTP server details are set up. Connectivity to FTP server as well as functionality can be tested.

**ENcombi** ADMIN

**FTP config**

FTP server: myftpserver.com

FTP path:

FTP client port: 21

FTP passive: ENABLED

FTP username: username

FTP password: \*\*\*\*\*

FTP setup page.  
 Path to sub folder on FTP server can be setup.  
 Path must be provided as indicated in below example.  
 /Folder/SubFolder/.  
 No path entered equals FTP server root directory.  
 Connectivity to a FTP server can be tested.  
 Transfer of an empty file FTPTest.txt can be tested.

Test: myftpserver.com

2020-07-10-13:12:58

On the same submenu level the set up of automatic FTP transfer is found. Clicking the up/down arrows will lead to it.

## Automatic FTP transfer

On the page below the automatic transfer of files is set up.

**ENcombi** ADMIN

**Auto FTP**

Event log: DISABLED

Summary log: DISABLED

Production log: DISABLED

Attempts: 3

Automatic FPT file transfer setup page.  
 Transmission of event log file can be triggered by  
 occurrence of alarms and/or events.  
 Transmission of summary log will occur  
 at midnight containing days result.  
 Transmission of production log will occur  
 at midnight containing full days production.  
 Number of re-transmission attempts can set.

2020-07-10-13:13:25

## ECpvh server access

The ECpvh features three servers:

1. FTP server.
2. Telnet server.
3. Web server (ECweb).

### ECpvh FTP server

First page presented when clicking the server button is the page below where the FTP server access details are set up.

Two sets of credentials exist.

1. Credential set0 will provide access to the PLC\_PRG folder on the SD-card.
2. Credential set1 will provide access to the Logs folder on the SD-card.

FTP server access in general can furthermore be enabled/disabled.

ENcombi ADMIN

FTP Server:

User0: ftp\_user0

Password0: \*\*\*\*\*

User1: ftp\_user1

Password1: \*\*\*\*\*

FTP: ENABLED

FTP server setup page.  
 Credential0 is for remote SW update via FTP.  
 Credential1 is for reading out logs via FTP.

2020-07-10-13:14:07

On the same submenu level the set up of telnet server access is found. Clicking the up/down arrows will lead to it.

### ECpvh Telnet server

On the below page the telnet server access is set up. It is normally not used as it is intended for debug purposes only by tracing various ECpvh client activities. Telnet server access in general can furthermore be enabled/disabled.

TELNET Server:

User0: telnet\_user0  
Password0: \*\*\*\*\*  
Telnet: ENABLED



Telnet server setup page.  
Credential is for device telnet server access.  
Telnet is usable for tracing various device client activities.

2020-07-10-13:14:30

On the same submenu level the set up of web server access is found. Clicking the up/down arrows will lead to it.

## ECpvh web server (ECweb)

On the page below the web server access is set up.

The HTTP port can be changed. This can be useful if to access ECpvh from outside the LAN using port forwarding and multiple ECpvh's or other devices also featuring a web server are connected to the LAN as well.

ENcombi

ADMIN

WEB Server:

User0: web\_user0

Password0: \*\*\*\*\*

HTTP port: 80

WEB server setup page.  
Credential is for device WEB server access.  
The HTTP port can be changed which can be useful if to setup  
port forwarding in a router/gateway to the device.


2020-07-10-13:14:49

## Identifiers

Under this tile overview of SW version installed and extras present in the ECpvh as well as set up of project details (name, location etc.), password scheme etc. are found.

## ECpvh information

First page presented when clicking the Identifiers is the below page where various details about the ECpvh such as extras available, SW version, serial number etc. Also the MAC address can be found which is to be used when registering the ECpvh in ECcloud.



**ENcombi** ADMIN

**Company:**

Name:	Website:	Contact:	Support:	Cloud service:
ENcombi	www.encombi.com	sales@encombi.com	support@encombi.com	www.encombi.online

**Product:**

Type:	Extras:	Project version:	Serial number:
ECpvh	-C-L-	1.00.0	202104230002

**Platform:**

Device type:	Device variant:	Chip type:	Rtos:	Version:
WP240X	COM	SC24	V2.07 FULL	V23.9.63.1

**Identifiers:**

Serial number 1:	Serial number 2:	MAC address:
F7D8CD475FC3B4ED	2EDC5B18730B0982	003056914972

2021-04-27-12:22:42

On the right hand side there are five submenus for.

1. Project details.
2. Password scheme.
3. Extras.
4. Metrics.
5. Backups.
6. Application

## Project details

Clicking the location button leads to the below page where project details such as site name and location can be entered. Site name is used for the topic when ECpvh sends out emails. Site name as well as location information is used when registering ECpvh in ECcloud as well as for data visualization in ECcloud after registration.

## Project details:

Site: Holstebrovej 75

Customer: Sterregaards

Installer: Claes

Install date: 2018-03-04

## Location details:

Country: Denmark

Region: Midtjylland

City: Viborg

Latitude: 56.4483

Longitude: 9.3786



Site details setup page.  
The site name will be used by the device as the  
"from-alias" when sending out Emails.

2020-07-10-13:19:03

## Password scheme

Clicking the log-in button leads to the below page where the password scheme can be enabled/disabled.

## Passw. scheme:

Timeout: 180 s

Scheme: DISABLED

## ECpanel

Show passw: DISABLED



Password editing scheme setup page.

The password editing scheme can be enabled/disabled by the administrator.  
Level required for editing other settings, start/stop of plant etc. can be configured on dedicated permission setup pages.  
If password scheme is disabled, all users logged into web server will have administrator rights.  
Default passwords:  
Administrator: Password0.  
Service: Password1.  
Operator: Password2.

The display of the ECpanel password in clear text on the ECpanel can be enabled.

2021-03-31-08:37:58

The password scheme holds four access levels:

1. Administrator.
2. Service.
3. Operator.
4. Viewer.

Required access levels of the various functionalities can be tailored by the customer as shown later. Whenever an attempt is made to alter/activate anything which is not allowed with the current access level, ECpvh will discard the command and populate a message text informing which access level is required to apply the command.

Viewer level is obtained just by logging on to ECweb.

When to change the access level the upper right text string informing about the current access level is to be clicked. Doing that leads to the below log-in page.

When logging in the requested access level and associated password is typed in. When the correct password is typed in the padlock will open. Hereafter the log-in button must be clicked. That will give the selected access level and take you back to the previous page.

When logging out just click the log-out button. The ECpvh will log out automatically when no editing occurs within the timeout period. Users will be degraded to Viewer level and must log in again as described above to regain the required access level.

When the password scheme is disabled as per default the user will have administrator rights.

Only an administrator can disable the password scheme.

Besides the enabling of the password scheme for ECweb itself, there is a setting for enabling visualization of the ECpanel password in clear text on the ECpanel itself. When disabled the ECpanel password is hidden on the ECpanel.

On the same submenu level the set up pages for Operator, Service and Administrator level passwords are found. Clicking the up/down arrows will lead to them.

## Passwords

Operator access or high is required for changing the Operator password.

Service access or high is required for changing the Service password.

Administrator access is required for changing the Administrator password.

three dedicated menus exist for changing the passwords. Below example for changing Operator password.

On the same submenu level the set up pages for tailoring access level required for executing various commands are found. Clicking the up/down arrows will lead to them.

## Permissions

The various access levels required are set as below example.

Only an administrator can change the access level required for the various functionalities.

## License & Extras

Clicking the extras button leads to the page below where the list of available extras are displayed alongside with which of them are present in the ECpvh. Activation of License as well as upgrading with new Extras are done from here.

The screenshot shows the ENcombi interface for license and extras management. At the top left is the ENcombi logo, and at the top right is an 'ADMIN' link. Below the logo, the word 'Extras:' is followed by a list of items, each with a lock icon and a description:

- A: Acquisition only
- C: Cloud service
- C TRIAL: Cloud service free trial
- H: Hybrid as a Service
- L: PV/genset plants, unlimitation PV capacity
- M: PV/genset plants, 500kW PV capacity limitation
- S: PV/genset plants, 100kW PV capacity limitation

In the center, a box contains the following text:

License and extras page.  
 Contact dealer for purchase of license and extras.  
 When purchased, the license or extras can be fetched  
 by the device either online or from a USB stick.  
 If online, the device must have access to the internet.  
 If from USB stick, goto [www.encombi.online](http://www.encombi.online) to download license.

To the right of the list are two buttons with binocular icons: 'Search online:' and 'Search on USB:'. In the top right corner, there is a red arrow icon pointing up.

At the bottom right of the page, the timestamp '2020-07-10-13:24:28' is displayed.

After purchase of License or any additional Extra(s) the ECpvh is upgraded in one of the following ways.

### Search online

The ECpvh will have to be connected to the internet for this approach. Click the binoculars button for "Search online". When successfully completed the ECpvh will request a reboot.

### Search on USB

The License and Extras for the specific ECpvh are to be downloaded from ECcloud on [www.encombi.online](http://www.encombi.online) and put on the root directory on a USB stick. Insert the USB stick in the USB port on the ECpvh and click the binoculars button for "Search on USB". The ECpvh will check the USB stick for the upgrade. When successfully completed the ECpvh will request a reboot.

## Metrics

Clicking the metrics button leads to the below page where the metrics to use by ECpvh can be set up. The ECpvh will use the selected metrics for various displays on ECweb as well as in ECcloud.

**Settings**

Currency: Euro

Volume: liter

Mass: kg



Metrics setup page.  
Selected units will be used for  
various associated counters and derivatives.

## Backups

Clicking the Backup button leads to the below page where the backups supported by ECpvh are managed. The ECpvh provides two backups.

1. Settings.
2. Counters.

Both types can be:

1. Generated and stored locally on internal memory of ECpvh.
2. Loaded into ECpvh project from internal memory of ECpvh.
3. Copied from internal memory of ECpvh to ENcombi cloud for safe storage.
4. Read from ENcombi cloud to internal memory of ECpvh.
5. Generated and stored on USB-stick.
6. Loaded into ECpvh project from USB-stick.

When reading backups from the cloud it will overwrite any existing backup already present on the internal memory of the ECpvh. The presents of and date of origin of the backups on internal memory are displayed.

Per default when reading backups from ENcombi cloud, the ECpvh will read backups generated by itself. If to clone an ECpvh this can be done by typing in the MAC address of the ECpvh you request to clone. Doing this ECpvh will read backups generated by that ECpvh instead.

ADMIN

Backup	Date	Action
Settings	2020-06-06-10:41:45	
Counters	N.A.	
MAC address:	0030569108A2	

Device backup page.  
Following backups can be made:

1: Settings backup.  
2: Counter backup.

The backups are saved and loaded locally on/from the device.  
One backup for each function exist only.  
Saving a new backup will overwrite any existing backup.

Backups can also be saved and read in/from cloud service.  
One backup for each function per device can be saved only.  
Reading a backup from cloud service,  
will overwrite any existing local backup.

Furthermore backups can be saved on and loaded  
from USB memory stick.

To clone a device, backups created from other devices  
can be read from the cloud and loaded.  
To do so, the MAC address of the device to clone from  
must be typed in. The refresh button resets to the  
MAC address of the device itself.

2020-07-10-13:25:29

## Application

Clicking the Application button leads to the page below. Here it can be selected which application is to be active.

ENcombi ADMIN

Application

Application: ECPV

Application swap page.  
Here it is set up which application to run.  
When toggling between applications, the device is to be reboot. Any settings made in the ECPV application will be lost in the process. Store a backup before leaving the ECPV project if any settings are made that is to be restored when reverting to the ECPV application. Browser needs refreshing when the device has rebooted.

2020-07-25-20:29:32

The following applications are available.

1. ECpvh.
2. ECpvh Service Tool.
3. ECpvh Boot

ECpvh is the default application and the one to use for the normal operation of the ECpvh. ECpvh Service Tool is a separate application that offers various tests and configurations features and the ECpvh Boot is a tool for updating both the ECpvh and the ECpvh Service Tool SW. The ECpvh Service Tool and the ECpvh Boot are treated in separate chapters.


When toggling between applications the device is to be rebooted. Any settings made in the ECpvh application will be lost in the process. Make a backup before leaving the ECpvh application if any settings are made that are to be restored when reverting to the ECpvh application once again. The browser needs refreshing when the device is rebooted after switching the application.

## Settings

Under this tile the setup of site specific parameters such as number and ratings of genset, grid connections, and inverters, which power meters are used, power and reactive control schemes etc. are found.

### RS485 COM ports

The ECpvh features two RS485 COM ports which are referred to as COM2 and COM3.



COM2 is the one found next to the power supply and COM3 is the one found next to the ethernet port.

- COM2 is reserved for interfacing to power meters and/or meteorological sensors.  
In case none of this is enabled, COM2 is acting as a slave port.
- COM3 is reserved for interfacing to inverters and/or meteorological sensors.  
In case none of this is enabled, COM3 is acting as a slave port.

First page presented when clicking the Settings tile is the below page where COM2 configuration is set up.

## COM2 port

Baudrate:	19200
Parity:	NO PARITY 1 STOP BIT
Timeout:	0.3 s
TX rate:	1.0 s
Slave ID:	1



COM2 Port setup page.  
Baudrates supported are 9600, 19200, 38400 and 115200.  
Power meter RTU communication is fixed on COM2.  
Sensor and IO module RTU communication is optional on COM2.  
In case none of these communications are enabled, COM2 is serving as a Modbus RTU slave.  
Slave ID is only used in case COM2 is serving as a slave.



2022-01-07-13:37:24

Baud rates supported are:

- 9600, 19200, 38400 and 115200

Parity supported are:

- "Parity one stop bit", "No parity", "Even parity" and "Odd parity".

When a COM2 port is acting as a master, the transmit rate can be used to control the rate at which the ECpvh transmits to the slaves.

The Slave ID is only used when a COM2 port is acting as a slave.

On the same menu level a similar setup page for COM3 configuration is found. Clicking the up/down arrows will lead to it.

On the right hand side there are seven submenus for.

1. PV related parameters.
2. Genset related parameters.
3. Mains related parameters.
4. Sensor related parameters.
5. IO module related parameters.
6. Alarm related parameters.
7. Overview.
8. Night time.
9. Simulation.
10. Modbus slave profiles.



## PV

### Ratings

Clicking the PV button leads to the below page where the rated values of the PV installation are set up.

**ENcombi** ADMIN

Rated	
Inverter S:	20.0 kVA
Inverter Q:	20.0 kVAr
Panel P:	20.0 kW

PV capacity setup page.  
S and Q refers to installed inverter capacity.  
P refers to installed PV panel capacity.

2021-03-28-14:04:03

### Measurements

On the same submenu level the setup page for the sensing methods are found. Clicking the up/down arrows will lead to it.

**ENcombi** ADMIN

Measurement	
Sensing method:	SUM ALL PHASES
kW Origin:	PV METER
kWh Origin:	ECPV2

PV measurement setup page.  
Sensing method determines if to base reference on the sum of all phases or 3 x sensing values.  
AC origin determines from which source the PV production arises.  
kWh origin determines from which source the genset energy production arises.

2022-09-27-20:22:05

Sensing method determines what power readings to base the calculated references upon. Two options are available.

1. Sum all phases.

## 2. 3 x sensing.

### *Sum all phases*

The control will work on the total loading of all phases.

### *3 x sensing*

Only one CT is installed, sensing the production in one phase only. The phase production measured is representative of the production on the other two phases. The ECpv2 will multiply the production sensed with three in order to get the total production.

kW origin determines from where to retrieve/calculate the PV power production.

Supported methods are:

1. PV meter.
2. Inverter acquisition.
3. Inverter master control.
4. Modbus page 03.
5. Mains Reading

### *PV meter*

Up to 16 power meters for sensing PV production can be installed. ECpv2 will summarize the contributions from each of the meters into one common total for the PV power being produced. One meter is required for each cluster of inverters having a common point of coupling to the AC busbar.

### *Inverter acquisition*

The ECpv2 can also take the power contribution of the individual inverters directly from their own power measurements via the inverter communication. This approach should be carefully considered as loop time of getting all the individual contributions increases with the number of inverters (when interfacing to them via Modbus RTU) thereby introducing latency in the controls.

### *Inverter master control*

Some inverter systems have a superior controller sitting on top acting as the point of interface from a superior controller such as the ECpv2. Examples hereof can be the Inverter Manager from SMA or Smartlogger from Huawei. These master controllers typically offer a summarized production of all the below inverter contributions on their own which the ECpv2 can use directly. Again the loop time needs to be considered when using this method.

### *Modbus page 03*

This will have ECpv2 use the PV power data written from a superior controller/SCADA to the ECpv2 proprietary modbus map page 3.

### *Mains Reading*

In some cases the power reading from the Mains meter will always be equal and opposite of the PV meter reading. This is the case for example if no Load or gensets are connected and the PV plant is exclusively exporting power to the grid. When this setting is selected, the negative of the Mains meter reading will be used as the kW origin for the PV plant.

kWh origin determines from where to retrieve/calculate the PV energy production. Supported methods are:

1. ECpv2.
2. Power meters

### *ECpv2*

Based on the kW measured, the ECpv2 integrates energy counters itself.

### *Power meters*

The ECpv2 will read the total energy counter from the power meters and summarize those.

ECpv2 will, based on this, derive daily, monthly and yearly energy counters.

The meter used must provide either the total energy counter or the total energy export counter in order to make use of this approach. Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various meter models.

<http://www.encombi.com/products/ECpv2/>

Note that all counters derived from energy counters remain linked to the ECpv2 energy counters still.

### *Reference*

On the same submenu level the setup page for PV references are found. Clicking the up/down arrows will lead to it.

**References**

Priority:	OFF
Mains lim:	100.0 %
DG lim:	100.0 %
Cosphi cap:	0.600 C
Cosphi ind:	0.600 I
Cosphi lim:	DISABLED
Sensing method:	SUM ALL PHASES

**Measurement**

kW Origin:	PV METER
kWh Origin:	ECPV



PV reference setup page.  
 Priority setting determines whether to prioritise P or Q reference over the other in case exceeding rated S inverter capacity.

Max dispatch limits can be set for parallel operation to both grid and gensets respectively. In case the reference is exceeding, the device will limit the P reference.

Cosphi cap and Cosphi ind outlines operating range of the inverters. In case enabled and reference exceeding, the device will limit the Q reference.

Sensing method determines if to base reference on the sum of all phases or 3 x sensing values.

AC origin determines from which source the PV production arises.

kWh origin determines from which source the genset energy production arises.

2021-03-28-14:05:03

Priority setting determines whether to prioritise P or Q reference over the other in case exceeding rated S inverter capacity.

Maximum power dispatch limits can be set for grid and genset operation respectively. In case the reference calculated by the control schemes exceeds the limits, then the reference will be truncated to the limits.

Cosphi cap and Cosphi ind outline the operating range of the inverters. In case enabled and reference exceeds the outlined range, the ECpvh will limit the Q reference.

Sensing method determines what power readings to base the calculated references upon. Two options are available.

1. Sum all phases.
2. 3 x sensing.

*Sum all phases*

The control will work on the total loading of all phases.

*3 x sensing*

Only one CT is installed, sensing the production on one phase only. The phase production measured is representative for the production on the other two phases. The ECpvh will multiply the production sensed with three in order to get the total production.

kW origin determines from where to retrieve/calculate the PV power production. Supported methods are:

1. PV meter.
2. Inverter acquisition.
3. Inverter master control.
4. Modbus page 03.

*PV meter*

Up to 16 power meters for sensing PV production can be installed. ECpvh will summarize the contributions from each of the meters into one common total for the PV power being produced. One meter is required for each cluster of inverters having a common point of coupling to the AC busbar.

### *Inverter acquisition*

The ECpvh can also take the power contribution of the individual inverters directly from their own power measurements via the inverter communication. This approach should be carefully considered as loop time of getting all the individual contributions increases with the number of inverters (when interfacing to them via Modbus RTU) thereby introducing latency in the controls.

### *Inverter master control*

Some inverter systems have a superior controller sitting on top acting as the point of interface from a superior controller such as the ECpvh. Examples hereof can be the Inverter Manager from SMA or Smartlogger from Huawei. These master controllers typically offer a summarized production of all the below inverter contributions on their own which the ECpvh can use directly. Again the loop time needs to be considered when using this method.

### *Modbus page 03*

This will have ECpvh use the PV power data written from a superior controller/SCADA to the ECpvh proprietary modbus map page 3.

kWh origin determines from where to retrieve/calculate the PV energy production. Supported methods are:

1. ECpvh.
2. Power meters

### *ECpvh*

Based on the kW measured, the ECpvh integrates energy counters itself.

### *Power meters*

The ECpvh will read the total energy counter from the power meters and summarize those.

ECpvh will, based on this, derive daily, monthly and yearly energy counters.

The meter used must provide either the total energy counter or the total energy export counter in order to make use of this approach. Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various meter models.

<http://www.encombi.com/products/ECpvh/>

Note that all counters derived from energy counters remain linked to the ECpvh energy counters still.

### *Ramp rates*

On the same submenu level the setup page for PV ramp rates are found. Clicking the up/down arrows will lead to it.

### Island

P ramp up:	2.0 %
P ramp down:	2.0 %
Q ramp up:	2.0 %
Q ramp down:	2.0 %



PV ramp rate setup page.  
Ramp P and Ramp Q down determines the rate of change of the P and Q references respectively.  
In case PV paralleling with gensets only and these are in reverse power or overload state the ramps will be bypassed in order to attempt to clear the hazardous situation.



### Grid-tied

P ramp up:	2.0 %
P ramp down:	2.0 %
Q ramp up:	2.0 %
Q ramp down:	2.0 %

2021-03-28-14:13:12

Ramp P and Ramp Q down determine the rate of change of the P and Q references respectively. Unique ramp rates are available for Island and Grid-tied operation respectively. In case PV paralleling with gensets only and these are in reverse power or overload state the ramps will be bypassed in order to attempt to clear the hazardous situation.

## Ramp threshold

On the same submenu level the setup page for Ramp threshold is found. Clicking the up/down arrows will lead to it. When starting the PV plant the ECpvh offers an initial ramp threshold to avoid the PV reference being ramped up before even connecting the inverters.

### Ramp thr.

P Target:	5.0 %
Ramp P Thr.:	1.0 %
Ramp Thr. del.:	10.0 s



PV ramp threshold setup page.  
The power reference will be kept at the target value.  
When the PV power exceeds the threshold value then the timer will start to run. When the time exceeds the threshold delay then the ramping is released.



2021-04-16-13:45:52

As long as the threshold delay is not elapsed, then the ECpvh will use the threshold power target as the active power reference with a unity power factor for the PV plant. The threshold timer will start to run when the PV power production exceeds the Power threshold. Once the timer elapses, then the ramping is released and the PV reference will be ramped to the actual target references.

## Tariff



On the same submenu level the setup page for PV Tariff is found. Clicking the up/down arrows will lead to it.

ENcombi ADMIN




---

Tarif

Export: 0.02 Euro/kWh



PV tariff setup page.  
The tariff for PV power produced.  
Used by device for calculating PV export save.



---

2021-03-28-14:13:34

This tariff is for revenue generated based on the PV generation alone. This revenue is referred to as PV export save.

## Counters

On the same submenu level pages for various PV related counters are found. Clicking the up/down arrows will lead to them.

- Produced energy (daily, monthly, yearly and total).
- Consumed energy (daily, monthly, yearly and total).
- PV DC Produced energy (daily, monthly, yearly and total).
- Curtailed energy (daily, monthly, yearly and total).
- Battery charged energy (daily, monthly, yearly and total).
- Battery discharged energy (daily, monthly, yearly and total).
- UPS load consumed energy (daily, monthly, yearly and total).
- PV export save (daily, monthly, yearly and total).
- Mains import save (daily, monthly, yearly and total).
- Fuel save (daily, monthly, yearly and total).
- Fuel expense save (daily, monthly, yearly and total).
- CO2 emission save (daily, monthly, yearly and total).

Below is an example.

Available	Active	Update
ACE:	344 kWh	<input type="text" value="0 kWh"/>
ACE YEAR:	344 kWh	<input type="text" value="0 kWh"/>
ACE MONTH:	344 kWh	<input type="text" value="0 kWh"/>
ACE DAY:	170 kWh	<input type="text" value="0 kWh"/>
Curtailed	Active	Update
ACE:	0 kWh	<input type="text" value="0 kWh"/>
ACE YEAR:	0 kWh	<input type="text" value="0 kWh"/>
ACE MONTH:	0 kWh	<input type="text" value="0 kWh"/>
ACE DAY:	0 kWh	<input type="text" value="0 kWh"/>
Curtaiment thrs.:	97.0 %	<input type="text" value="97.0 %"/>

2021-04-27-08:30:02

The counters will be incremented automatically by the ECpvh in accordance with operation conditions. The counters are part of the counters backup discussed in the Identifier chapter.

The menus are only providing the possibility for manually presetting of the counters. Counters with a check mark in the update column will be preset with the keyed in value when the save button is pressed. Toggle between check mark and cross mark by pressing the respective buttons.

Curtailment threshold determines how close actual PV power production must be to the power reference before ECpvh interprets it as curtailment is ongoing. Curtailment state can only be set in case reference is below 100%.

## Meter

Clicking the power meter button on the right hand side of any of the above pages leads to the following page.

ENcombi ADMIN

**PV**

Power meter: OFF

Modbus type: RTU

ID: 2

IP: 192.168.1.50

Number: 1

**PV power meter setup page.**  
 A maximum of 16 power meters for PV is supported.  
 The same make/model must be used for all PV measurements.  
 The communication can be either Modbus RTU or TCP.

The Modbus IDs of the meters must be sequential  
 in case of RTU, with lowest ID being equal to the  
 setting made in the device.

The IP addresses of the meters must be sequential.  
 in case of TCP, with lowest IP address being equal to the  
 setting made in the device.

The Modbus ID selected is used in the TCP frames.

Port settings is setup on dedicated port setup page.

2020-07-10-13:32:28

A maximum of 16 power meters for PV is supported. The same make/model must be used for all PV measurements. The communication can be either Modbus RTU or TCP. Check the below link to see which meters are supported by ECpvh.

<http://www.encombi.com/products/ECpvh/>

Should your preferred meter not be on the list already, contact ENcombi to request the adding of it.

The Modbus IDs of the meters must be sequential in case of RTU, with lowest ID being equal to the setting made in the ECpvh.

The IP addresses of the meters must be sequential in case of TCP, with the lowest IP address being equal to the setting made in the ECpvh. The Modbus ID selected is used in the TCP frames.

Meter communication on Modbus RTU runs on RS485 COM2 port as discussed earlier in this chapter.

## Relay

On the same submenu level the page for setting up relay outputs on the power meters is found. Clicking the up/down arrows will lead to them.

## PV relay 1

Enable: DISABLED

Type: NO

## PV relay 2

Enable: DISABLED

Type: NO



PV meter relay setup page.  
The relay needs to be enabled with the intended functionality.  
Furthermore normal state "open" or "closed" can be set.

2020-07-10-13:32:54

A total of two relay outputs can be controlled.

The relay needs to be enabled with the intended functionality.

1. Disabled
2. Alarm
3. EClogic

Furthermore the relay can be configured to be normally open or normally closed.

Relay control is not supported for all the power meters. Consult the Modbus Master documentation on ENcombi website to learn for which power meters relay feature is support:

<http://www.encombi.com/products/ECpvh/>

### CT settings

On the same submenu level the page for setting up CT and VT settings for the power meters is found. Clicking the up/down arrows will lead to them. This feature applies for the Pilot SPM32 and SPM33 meters only. The Pilot meter CT and PT settings will by default automatically be read from the SPM32 and SPM33 power meters. If the CT and VT used on all PV meters are the same you can choose to type them in here and then have the ECpvX use those settings. This will speed up the loop time polling rate.

**PV**

CT1: 5 A

PT1: 22 times 10V

PT2: 220 V

Enable: DISABLED



PV meter CT and PT setup page.  
 The Pilot meter CT and PT settings will per default automatically be read from the SPM32 and SPM33 power meters. If the CT and VT used on all PV clusters are the same you can choose to type them in here and then have the ECpVX use those settings. This will speed up the loop time polling rate for the meters.

2023-08-31-09:58:12

### Frame settings

On the same submenu level the frame setup is found. Modbus frames that only contain either energy counters or digital inputs can be disabled from this page. This will speed up the loop time polling rate for meters using separate KWH or DIGIN frames.

**Frame:**

KWH Frame: ENABLED

DIGIN Frame: ENABLED



PV meter frame setup page.  
 Modbus frames containing only energy counters or digital inputs can be disabled individually. This will speed up the loop time polling rate for meters using separate KWH or DIGIN frames.

2024-04-16-14:37:23

## Inverter

Clicking the inverter button leads to the following page.

The screenshot shows the ENcombi web interface for inverter configuration. On the left, there is a table of settings:

Inverter	
Protocol:	OFF
Modbus type:	RTU
Control Fnc:	0x10
Control:	ENABLED
Data acquisition:	ENABLED
Number:	4

In the center, there is a box with the following text:

Inverter setup page.  
 The device can interface to inverters via Modbus RTU or Modbus TCP.  
 Besides controlling the inverters, the device can also do data acquisition. If data acquisition enabled, the device will read production data from all the inverters.  
 The data read, will be visualized on dedicated page.

On the right, there is an 'ADMIN' menu with a grid icon and an upward-pointing arrow.

At the bottom right of the page, the timestamp '2020-07-10-13:33:20' is visible.

A maximum of 16 inverters is supported by a single ECpvh. In case more than 16 inverters are to be controlled, multiple ECpvh can be stacked to work together. This is discussed in a separate chapter later in this document. All inverters controlled by a single ECpvh must be of the same vendor and possibly model. The communication can be either Modbus RTU or TCP.

Check the below link to see which inverters are supported by ECpvh.

<http://www.encombi.com/products/ECpvh/>

Should your preferred inverter not be on the list already, contact ENcombi to request the adding of it.

Controlling the inverters and data acquisition from the inverters can be enabled/disabled independently. ECpvh supports Modbus function code 0x06 and 0x10 for applying control commands. Some inverters support only one of the two. Consult the Modbus Master documentation on ENcombi website to learn which function code to use with your inverter:

<http://www.encombi.com/products/ECpvh/>

If data acquisition is enabled, the data read from the inverters, will be visualized on dedicated pages under monitoring.

## RTU

On the same submenu level the page for setting up Modbus RTU specifics for inverter communication is found. Clicking the up/down arrows will lead to it.

## RTU

Control type:	UNICAST
Initialization ID:	0
Broadcast ID:	0
Control ID:	1
Acquisition ID:	1



Inverter interface via Modbus RTU setup page.

The device can apply references as Unicast or as Broadcast. Unicast is applicable when interfacing to a single unit. This being a single inverter or a controller managing a pool of inverters. Broadcast is applicable for controlling a pool of inverters without the presents of a managing controller.

The modbus broadcast ID is configurable. Default and modbus standard is 0.

The Control ID is used for Unicast. If a managing controller is present the Control ID is to match that device. If no managing controller is present, the Control ID shall be set equal to the Acquisition ID.

The Identification ID used for protocol map identification routine.

The Acquisition ID shall be set equal to the lowest inverter ID present. When Acquisition enabled the device will read data from the inverters. The device will read from Acquisition ID on onwards, until the number of inverters selected is reached. The IDs of the inverters must be sequential.

2020-07-10-13:33:48

The ECpvh can apply references as Unicast or as Broadcast. Unicast is applicable when interfacing to a single unit. This being a single inverter or a controller managing a pool of inverters. Broadcast is applicable for controlling a pool of inverters without the presents of a managing controller.

The Control ID is used for Unicast. If a managing controller is present the Control ID is to match that device. If no managing controller is present, the Control ID shall be set equal to the Acquisition ID.

If the inverters do not support Broadcast, a pool of inverters can be controlled using Unicast still. In this case Control ID shall be set equal to the Acquisition ID.

The Initialization ID is used for any protocol initialization routine such as SunSpec map identification.

The Acquisition ID shall be set equal to the lowest inverter ID present. When Acquisition enabled the device will read data from the inverters. ECpvh will read from Acquisition ID and onwards, until the number of inverters selected is reached. The IDs of the inverters must be sequential.

## TCP

On the same submenu level the page for setting up Modbus TCP specifics for inverter communication is found. Clicking the up/down arrows will lead to it.

## TCP

Control IP: 192.168.1.50

Acquisition IP: 192.168.1.50

TCP-RTU converter: DISABLED



Inverter interface via Modbus TCP setup page.

When controlling a pool of inverters, without the presents of a managing controller, the Control IP is to be set differently than the Acquisition IP. The RTU Initialization ID is in this case used for any initialization frames. The RTU Control ID is in this case used for all other frames. The IP addresses of the inverters must be sequential.

When controlling a single inverter or a pool of inverters with the presents of a managing controller, the Control IP is to be set equal to the Acquisition IP. The RTU Initialization ID is used for any initialization frames. The RTU Control ID is used for the control frames. The RTU Acquisition IDs are used for the data acquisition frames.

When controlling a single inverter or a pool of inverters via TCP-RTU converter, the Control IP is to be set equal to the Acquisition IP. The RTU Initialization ID is used for any initialization frames. The RTU Control IDs are used for the control frames. The RTU Acquisition IDs are used for the data acquisition frames.

2020-07-10-13:40:48

When controlling a pool of inverters, without the presence of a managing controller, the Control IP is to be set differently than the Acquisition IP.

- The RTU Initialization ID is used for all TCP frames related to protocol initialization routine such as the SunSpec map identification.
- The RTU ControlID is used for TCP frames for both acquisition and control references. The IP addresses of the inverters must be sequential.

When controlling a single inverter or a pool of inverters with the presence of a managing controller, the Control IP is to be set equal to the Acquisition IP.

- The RTU Initialization ID is used for all TCP frames related to protocol initialization routine such as the SunSpec map identification.
- The RTU Control ID is used for the TCP frames related to control references.
- The RTU Acquisition IDs are used for the TCP frames related to data acquisition.

Controlling a single inverter or a pool of inverters via a TCP/RTU converter can be useful sometimes if ECpvh is to co-exist with a datalogger for instance. In this case the Control IP is to be set equal to the Acquisition IP.

- The RTU Initialization ID is used for all TCP frames related to protocol initialization routine such as the SunSpec map identification.
- The RTU Control ID is used for the TCP frames related to control references.
- The RTU Acquisition IDs are used for the TCP frames related to data acquisition.

This approach is not recommended with big inverter clusters as the Modbus TCP from ECpvh will give references to the inverters individually. When passing this through TCP/RTU converter the speed is limited to the serial line performance slowing this way down. For big clusters of inverters going directly with Modbus RTU from ECpvh via a serial line multiplexer is considered the best option as references can then be applied as broadcast commands.

## Advanced Inverter command setup

On any of the above inverter pages clicking the Command button will lead to the below page for advanced inverter command setup.

## Common inverter command setup

**ENcombi** ADMIN

Inverter Cmd	
Interval:	300.0 s
P timeout:	60 s
Q timeout:	60 s

Common inverter command setup page.  
 The delay between transmission of commands that is set to be transmitted at defined interval and reference fallback timeout values can be set here.  
 Protocol specific command configuration is found on the following pages.

2020-07-10-13:41:08

These settings are common for all inverters and may or may not apply to the specific inverter make/model selected. Here the delay between transmission of commands that is set to be transmitted at a defined interval can be set. Furthermore the fallback timeouts for reverting to predefined production level in case of loss of communication can be set up.

## SunSpec inverter command setup

Clicking the up/down button will lead to the SunSpec command setup page.

**ENcombi** ADMIN

SunSpec Cmd	
P enable:	CONTINUOUSLY
Q enable:	CONTINUOUSLY
P timeout:	DISABLE
Q timeout:	DISABLE
P scale:	AUTOMATIC
Q scale:	AUTOMATIC

SunSpec command setup page.  
 The commands for enabling of P and Q references can be disabled, transmitted at defined interval or be transmitted continuously.  
 The commands for timeout of P and Q references can be disabled, transmitted at defined interval or be transmitted continuously. The timeout values to sent are set up on the common inverter command page.  
 The resolution used for power and reactive power references can be adjusted.

2020-11-18-12:07:05

For SunSpec protocol the commands for enabling P and Q references can be disabled, transmitted at a defined interval or be transmitted continuously. The same is the case for the transmission of the fallback timeout values.

The number of decimals used when applying the power and reactive power control commands can be adjusted. Default selection is "Automatic" as this is detected as part of SunSpec. However, in some cases it is found that the inverter vendors implementation is not according to the standard (due to old SW in the inverter or similar) and in those cases the automatics can be overruled and the number of decimals used can be fixed in accordance with the actual behavior of the inverter.

It can further be enabled/disabled whether to include the Multiple MPPT Extended Inverter Model (I160) as part of the inverter data acquisition.

### Secondary inverter setup

Clicking the up/down button will lead to the Secondary inverter setup page.

#### Secondary inverter

Protocol:	OFF
Control Fnc:	0x10
Number:	1
Control:	DISABLED
Data acquisition:	DISABLED



**Secondary inverter setup page.**  
The device can control a PV plant with a mix of up to two different inverter models.

On this page a secondary inverter model can be enabled. It is enabled by selecting a protocol and how many of the total number of inverters present that are of the secondary type.

On the primary inverter setup page inverter, the number of inverters to set must be the total number of inverters in the plant.

Secondary inverter support only applies for Non SunSpec protocols running on Modbus RTU and using Unicast command method.

The modbus IDs of all the inverters must be sequential with the primary inverters having the lowest IDs in the sequence.

The ECpvh can control a PV/Hybrid plant with a mix of up to two different inverter models.

On this page a secondary inverter model can be enabled. It is enabled by selecting a protocol and how many of the total number of inverters present that are of the secondary type. On the primary inverter setup page inverter, the number of inverters to set must be the total number of inverters in the plant. Secondary inverter support only applies for Non SunSpec protocols running on Modbus RTU and using the Unicast command method. The modbus IDs of all the inverters must be sequential with the primary inverters having the lowest IDs in the sequence.

### Multiple inverter cluster setup


Clicking the up/down button will lead to the pages for setting up multiple inverter clusters. An inverter cluster in this context is defined as one or more inverters being connected to a superior datalogger like a Huawei Smartlogger, a Sungrow COM100E or

a SMA InverterManager. The ECpvH can control up to 16 inverter clusters. Note that data


acquisition of the individual inverters is limited to a maximum of 16 inverters. In the menu below it is set up how the total installed inverter capacity is split between the individual inverter clusters.

ENcombi ADMIN

Cluster capacity	
Cluster 1:	50.0 %
Cluster 2:	50.0 %
Cluster 3:	0.0 %
Cluster 4:	0.0 %
Cluster 5:	0.0 %
Cluster 6:	0.0 %
Cluster 7:	0.0 %
Cluster 8:	0.0 %

Inverter cluster setup page.  
The device can control a PV plant made up of multiple inverter clusters each being connected to a superior datalogger like the Huawei Smartlogger or the Sungrow COM100E.  
On this page the capacity of each of these clusters are to be set. It is set in percentage of the total installed inverter capacity in the entire PV plant.





2022-06-28-11:59:10


In the menu below it is set up how many inverters are present in the individual clusters.

ENcombi ADMIN

Cluster inverter nbr	
Cluster 1:	4
Cluster 2:	6
Cluster 3:	0
Cluster 4:	0
Cluster 5:	0
Cluster 6:	0
Cluster 7:	0
Cluster 8:	0

Inverter cluster setup page.  
The device can control a PV plant made up of multiple inverter clusters each being connected to a superior datalogger like the Huawei Smartlogger or the Sungrow COM100E.  
On this page the number of inverters present in each of these clusters are to be set.



2022-06-28-12:00:38

The IP addresses of the superior dataloggers of the inverter cluster must come in a sequential order. Furthermore the Modbus IDs of the inverters in the individual clusters must be sequential and the Modbus ID sequence in each inverter page cluster must start at the same value.

When making a multi cluster plant then the setting normally used for the number of inverters being present is instead referring to the number of inverter clusters (superior data loggers) being present.

### Inverter PID control

On the same submenu level the page for configuring PID control of the Inverters can be found. Clicking the up/down arrows will lead to it.

**P PID**

Enable: DISABLED

Kp: 0.1

Ki: 0.025

Kd: 0.1

**Q PID**

Enable: DISABLED

Kp: 0.1

Ki: 0.025

Kd: 0.1



Inverter PID setup page.  
Per default the inverter control is open loop.  
Here closed loop PID control can be enabled and adjusted.  
It can be selected whether to make the control using  
the active and reactive power adjustment control  
registers directly or indirectly via the voltage and frequency  
adjustment control registers instead.

2024-02-20-12:56:17

By default the PID control is disabled and the inverter control is open loop. Closed loop inverter control can help achieve the desired power output when controlling multiple inverters even if one or more of them are not producing the correct power. Active and reactive power closed loop control can be enabled separately.

## Genset

### References

Clicking the genset button leads to the page below where the reference used when parallelling PV to genset(s) are used.

**ENcombi** ADMIN

**References**

Min. genset load:	30.0 %
Genset Q ctrl:	ALL Q
Cosphi cap:	0.800 C
Cosphi ind:	0.950 I
Sensing method:	SUM ALL PHASES

**Measurement**

GB Feedb. origin:	GENSET POWER
Threshold:	0.00 kW
kW Origin:	GENSET METER
kWh Origin:	ECPV

**Genset reference setup page.**  
References applies when running parallel to gensets only.

The device will regulate PV power production in order to keep gensets connected running at the minimum genset load setting.

Genset Q ctrl determines the reactive power regulation.  
All Q: Gensets carry all the reactive loading until limits reached.  
Sharing Q: Same reactive loading on PV plant and gensets.  
Same cosphi: Same cosphi on PV plant and gensets.  
Fixed cosphi C DG: Fixed cap cosphi on the gensets.  
Fixed cosphi I DG: Fixed ind cosphi on the gensets.  
All Q no limits: Gensets carry all the reactive loading.

Cosphi cap and cosphi ind outlines the operating range of the gensets.  
In case compromised, the PV will pick up excessive reactive loading in order to keep gensets within their operating range.  
This applies only for the selection "All Q" in Genset Q ctrl. setting.

Sensing method determines if to base reference on the sum of all phases, 3 x lowest loaded phase or 3 x sensing values.

GB feedback origin determines from which source the genset breaker position feedbacks arises.

kWh origin determines from which source the genset energy production arises.

2021-01-13-12:34:46

ECpvh will regulate PV power production in order to keep gensets connected running at the minimum genset load setting.

Genset Q ctrl determines the reactive power regulation. Three options are available.

- All Q: the ECpvh will let the gensets carry all the reactive loading until they reach the cosphi limits.
- Sharing Q: the ECpvh will keep the same reactive loading on the PV plant and gensets.
- Same cosphi: the ECpvh will keep the same cosphi on the PV plant and gensets.
- Fixed cosphi C DG: the ECpvh will keep a fixed capacitive cosphi on the genset. The reference is determined by the "Cosphi cap" setting.
- Fixed cosphi I DG: the ECpvh will keep a fixed inductive cosphi on the genset. The reference is determined by the "Cosphi ind" setting.
- All Q no limits: the ECpvh will let the gensets carry all the reactive loading.

Cosphi cap and Cosphi ind outlines the operating range of the gensets. In case compromised the ECpvh will pick up excessive reactive loading in order to keep gensets within their operating range. This applies only when "All Q" selection is made in Genset Q ctrl. setting.

Sensing method determines what power readings to base the calculated references upon. Three options are available.

1. Sum all phases.
2. 3 x lowest phase.
3. 3 x sensing.

#### *Sum all phases*

The control will work on the total loading of all phases not regarding any potential asymmetry. Using this method with asymmetrical loads and a low minimum genset load can result in a situation where the load on individual phase(s) gets very low with the risk of reversing.

#### *3 x lowest phases*

The control will identify the least loaded phase and multiply this with three. This can be useful when load is asymmetrical avoiding the phenomenon described above. The net loading on the genset will be somewhat higher than the minimum genset load setting dictates but it will diminish the potential risk of feeding power into the genset(s) on the low loaded phase(s).

#### *3 x sensing*

This can be used when load is symmetrical. Only one CT is installed, sensing the load from one phase only. The phase load sensed is being representative for the loading on the other two phases. The ECpvh will multiply the load sensed with three in order to get the total load.

GB feedback origin determines from which source the genset(s) breaker position closed feedback arises. Three options are available.

- Power meter / genset controller.
- Genset power.
- EClogic.
- Modbus page 03.

#### *Power meter*

In case a power meter is used instead of a direct interface to a genset controller, the input1 of the power meter will be interpreted as genset breaker closed feedback. If interfacing to a genset controller, the genset breaker closed feedback will already be wired to the genset controller and can in most cases be read directly by ECpvh.

#### *Genset power*

Whether a gensets breaker is closed can also be detected on the power reading itself. If a power is read from the power meter that exceeds the threshold, both positive and negative, the associated genset breaker is interpreted as being closed.



*EClogic*

In more complex electrical infra structures having for instance sectional breakers separating part of the gensets from the PV plant, a condition of whether the gensets are at all connected to the same AC busbar section as the PV needs to be taken into consideration. Such conditions can be customized from within EClogic.

*Modbus page 03*

This will have ECpvh use the GB feedback data written from a superior controller/SCADA to the ECpvh proprietary modbus map page 3.

kW origin determines from where to retrieve/calculate the genset power production. Supported methods are:

1. Genset meter.
2. Modbus page 03.

*Genset meter*

Up to 16 power meters for sensing Genset production can be installed. ECpvh will summarize the contributions from each of the meters into one common total for the genset power being produced.

*Modbus page 03*

This will have ECpvh use the genset power data written from a superior controller/SCADA to the ECpvh proprietary modbus map page 3.

kWh origin determines from where to retrieve/calculate the genset energy production. Supported methods are:

1. ECpvh.
2. Power meters

*ECpvh*

Based on the kW measured, the ECpvh integrates energy counters itself.

*Power meters*

The ECpvh will read the total energy counter from the power meters and summarize those.

ECpvh will, based on this, derive daily, monthly and yearly energy counters.

The meter used must provide either the total energy counter or the total energy export counter in order to make use of this approach. Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various meter models.

<http://www.encombi.com/products/ECpvh/>



Note that all counters derived from energy counters remain linked to the ECpvh energy counters still.

## Tariffs

On the same submenu level the setup page for genset tariffs is found. Clicking the up/down arrows will lead to it.

ENcombi ADMIN




Tarif	
Efficiency:	0.25 liter/kWh
Price:	1.25 Euro/liter
Emission:	2.64 kg/liter

**Genset tarif setup page.**  
 Efficiency is used for calculating fuel volume consumed by the gensets as well as fuel volume saved by the PV plant.

Price is used for calculating fuel expense of the fuel volume consumed by the gensets as well as for the fuel expense spared by the PV plant.

Emission is used for calculating the CO2 emission generated fuel volume consumed by the gensets as well as for the CO2 emission spared by the PV plant.

2021-01-05-15:02:42

Efficiency is used for calculating fuel volume consumed by the gensets as well as fuel volume saved by the PV plant.






Price is used for calculating fuel expense of the fuel volume consumed by the gensets as well as for the fuel expense saved by the PV plant.

Emission is used for calculating the CO2 emission generated fuel volume consumed by the gensets as well as for the CO2 emission saved by the PV plant.

## Rated sizes

On the same submenu level the setup pages for gensets rated power are found. Clicking the up/down arrows will lead to them.

ENcombi ADMIN

Rated			
Genset 1:	100.0 kW	  <div style="border: 1px solid black; padding: 10px; text-align: center; width: fit-content; margin: 0 auto;">Genset capacity setup page.</div>	  
Genset 2:	100.0 kW		
Genset 3:	100.0 kW		
Genset 4:	100.0 kW		
Genset 5:	100.0 kW		
Genset 6:	100.0 kW		
Genset 7:	100.0 kW		
Genset 8:	100.0 kW		

2021-01-05-15:03:15

A total of 16 gensets are supported. Above page is one of two pages available for setting up the rated genset sizes.

## Counters

On the same submenu level pages for various genset related counters are found. Clicking the up/down arrows will lead to them.

- Produced energy (daily, monthly, yearly and total).
- Fuel consumed (daily, monthly, yearly and total).
- Fuel expense (daily, monthly, yearly and total).
- CO2 emission (daily, monthly, yearly and total).

Below is an example.

**Produced**

Active	Update
ACE: 0 kWh	450 kWh <input checked="" type="checkbox"/>
ACE YEAR: 0 kWh	500 kWh <input checked="" type="checkbox"/>
ACE MONTH: 0 kWh	400 kWh <input checked="" type="checkbox"/>
ACE DAY: 0 kWh	410 kWh <input checked="" type="checkbox"/>

**Fuel consumed**

Active	Update
Total: 0 liter	0.0 <input checked="" type="checkbox"/>
Year: 0 liter	0.0 <input checked="" type="checkbox"/>
Month: 0 liter	0.0 <input checked="" type="checkbox"/>
Day: 0 liter	0.0 <input checked="" type="checkbox"/>

Genset production counters preset page.  
Counters with checkmark in the update column will be preset with keyed in value when save button is pressed. Toggle between checkmark and crossmark by pressing the button.

ADMIN

2021-01-05-15:11:48

The counters will be incremented automatically by the ECpvh in accordance with operation conditions. The counters are part of the counters backup discussed in the Identifier chapter.

The menus are only providing the possibility for manually presetting of the counters. Counters with a check mark in the update column will be preset with the keyed in value when the save button is pressed. Toggle between check mark and cross mark by pressing the respective button.

## Meter

Clicking the power meter button on the right hand side of any of the above pages leads to genset meter configuration. The genset meter configuration is done in the exact same manner as the already covered PV power meter configuration. Refer to PV power meter configuration for setting up of power meters.

## Genset management

Clicking the genset management meter button on the right hand side of any of the above pages leads to the genset management configuration.

## Load dependent start/stop

First page presented is the below page where Load depending start/stop scheme is configured.

## LD start/stop

LD start:	80.0 %
LD start delay:	10.0 s
LD stop:	60.0 %
LD stop delay:	30.0 s
Start target:	100.0 kW
Spinning res.:	0.0 %
Enable:	DISABLED



Genset management setup page.

**NON SYNC:**  
Load depending start/stop scheme for non-synch gensets. the device can do load depending start/stop handling of gensets.

The start/stop commands can in some cases be sent directly to the gensets via the communication to the genset controllers. Alternatively the start/stop commands can be linked to relay outputs via EClogic.

Load depending start/stop thresholds in percentage plus associated delays are available. The load depending start/stop thresholds are based on sum of genset load and PV spinning reserve contribution.

When genset start button is pushed initially the device will start suitable genset in accordance with the start target load.

Power measurement must be used for genset breaker position detection.

**SYNC SR:**  
Spinning reserve scheme for synchronized gensets. The actual load depending start/stop is in the scope of the genset control system. The device manipulates the PV output to provoke/prevent load depending start and stops in the genset system to secure a sufficient spinning reserve to withstand a loss of PV production.

2021-03-25-14:09:17

The ECpvh can do load depending start- and stop handling of gensets for two types of genset systems.

1. Non-Sync.  
Routine for non synchronising gensets.
2. Sync SR.  
Routine for synchronising gensets with its own build in load depending start/stop scheme.

### Non-sync.

This routine is for non-synch gensets. The ECpvh will at all times only request for one genset to be connected and when swapping gensets it will make certain that one is disconnected before the next one is started and connected.

The start/stop commands can in some cases be sent directly to the gensets via the communication to the genset controllers. Consult the Modbus master documentation on ENcombi website to find out which supports this:

<http://www.encombi.com/products/ECpvh/>

Alternatively the start/stop commands can be linked to relay outputs via EClogic. Consult the Modbus slave documentation on ENcombi website for details on addresses to use:

<http://www.encombi.com/products/ECpvh/>

The load depending start threshold is compared to the sum of genset loads and the PV spinning reserve contribution. The PV spinning reserve contribution is a percentage of the actual load carried by the PV plant. When the condition is fulfilled for the selected load depending start delay, the ECpvh will start a larger, more suitable genset for the load if available.

The load dependent stop threshold is compared to the sum of genset load and PV load. This is to make certain that when a smaller gensets is started to replace a bigger running genset that it will be able to carry the full load present which it will have to as PV production is temporarily lost when transitioning from the big to the small genset.

When genset management is enabled an additional start/stop button appears on the monitoring pages (see later) for starting and stopping of the genset plant. When the genset start button is pushed initially, the ECpvh will start a suitable genset in accordance with the start target load.

“Genset Power” must be selected as the means for GB feedback detection.

Sync SR.

This routine is for synchronising gensets with its own build in load depending start/stop scheme.

The actual load depending start/stop is carried out by the genset control system but the ECpvh will manipulate the loading on the gensets (via control of the PV production) to provoke/prevent load depending start and stops. The ECpvh does so based on the Spinning reserve requested in the genset system. The PV spinning reserve request is the percentage setting set of the actual load carried by the PV plant.

To be able to withstand a complete loss of PV production at all times, the Spinning reserve should therefore be set to 100%. If the genset capacity needed (actual load plus the spinning reserve request) on the AC bus exceeds the load depending start threshold, then the ECpvh will, after the load depending start delay expires, bring the genset up to that load depending start load by curtailing the PV. This will provoke a load depending start in the genset system bringing an additional genset online.

Similar, if the genset capacity needed (actual load plus the spinning reserve request) on the AC bus will exceed the load depending stop threshold after the potential stopping of a genset, then the ECpvh will keep the gensets at the load depending stop threshold load to prevent the genset system from stopping down a genset.

Eventually if the load drops further and the genset capacity needed (actual load plus the spinning reserve request) on the AC bus will not exceed the load depending stop threshold after the potential stopping of a genset, then the ECpvh will, after the load depending stop delay expires, bring the gensets to their minimum operating load which will result in the genset system stopping down a genset.

The genset system should be set up to do load depending start/stop calculations in percentage. It is recommended to set the load depending start/stop thresholds in the ECpvh a few percentage higher than they are set in the genset system. If the gensets are of different ratings, then the genset start priority should be set in the same order as the modbus ID meaning that the one with the lowest Modbus ID has first priority and so on.

## Genset start/stop failures

On the same submenu level the setup page for genset start/stop failures are found. Clicking the up/down arrows will lead to it. This only applies for the Non-Sync routine only.

## ENcombi

ADMIN

## DG start fail.

Fail. delay: 30.0 s

Enable: DISABLED

Auto ack.: DISABLED



**Genset start/stop failure setup page.**

If genset start command is given and genset not on line within defined time a start failure is raised. That specific genset will not be considered available any longer until alarm is cleared. Manual alarm acknowledge will clear the alarm on all the gensets. Autoacknowledge will clear the alarm on all the gensets in case all gensets present are having start failure.

If genset stop command is given and genset not off line within defined time a stop failure is raised. In case stop failure is present all start commands are suppressed. All gensets must be off line before start command to new genset is given.

## DG stop fail.

Fail. delay: 30.0 s

Enable: DISABLED

Auto ack.: DISABLED

2020-07-10-13:46:24

If the genset start command is given and a genset is not on line within defined time a start failure is raised. That specific genset will not be considered available any longer until the alarm is cleared. Manual alarm acknowledge will clear the alarm on all the gensets.

Auto acknowledge will clear the alarm on all the gensets in case all gensets present are having start failure.

If the genset stop command is given and the genset is not offline within defined time a stop failure is raised. In case stop failure is present all start commands are suppressed. All gensets must be offline before the ECpvh sends the start command to a new genset.

## Mains

### Measurements

Clicking the mains button leads to the page below where the sensing methods used when parallelling PV to utility are used.

The screenshot shows the 'Mains measurement setup page' in the ENcombi interface. On the left, there is a table with the following configuration:

Measurement	
Sensing method:	SUM ALL PHASES
MB Feedb. origin:	FIXED ON
KW Origin:	MAINS METER
kWh Origin:	ECPV2

The central text box contains the following information:

**Mains measurement setup page.**

Sensing method determines if to base reference on the sum of all phases, 3 x lowest loaded phase or 3 x sensing values.

MB feedback origin determines from which source the mains breaker position feedbacks arises.

kWh origin determines from which source the mains energy production arises.

At the bottom right of the screenshot, the date and time '2024-08-21-13:32:21' are displayed.

Sensing method determines what power readings to base the calculated references upon. Three options are available.

1. Sum all phases.
2. 3 x lowest phase.
3. 3 x sensing.

#### *Sum all phases*

The control will work on the total loading of all phases not regarding any potential asymmetry. Using this method with asymmetrical loads can in a self consumption situation for instance result in a situation where the net power feed to grid is in fact 0kW but there is import on some phase(s) and export on other phase(s).

#### *3 x lowest phases*

The control will identify the least loaded phase and multiply this with three. This can be useful when load is asymmetrical avoiding the situation described above. The net import power from the grid may not be 0kW but exporting power on any of the three phases is avoided.

#### *3 x sensing*

This can be used when load is symmetrical. Only one CT is installed, sensing the load from one phase only. The phase load sensed is representative for the loading on the

other two phases. The ECpv2 will multiply the load sensed with three in order to get the total load.

MB feedback origin determines from which source the mains breaker position closed feedbacks arises.

- Fixed on.
- Power meter.
- EClogic.
- All GB off
- Modbus page 03.

#### *Fixed on*

In case of sites without gensets where ECpv2 is used for self consumption operation alone for example, the mains breaker position can always be assumed to be closed.

#### *Power meter*

In case a power meter is used the input1 of the power meter will be interpreted as mains breaker closed feedback.

#### *EClogic*

In more complex electrical infra structures having for instance sectional breakers separating the utility from the PV plant, a condition of whether the utility is at all connected to the same AC busbar section as the PV needs to be taken into consideration. Such conditions can be customized from within EClogic.

#### *All GB off*

In case all GBs are off and there is no genset communication alarm present, the ECpv2 will interpret this as the mains breaker position is closed.

#### *Modbus page 03*

This will have ECpv2 use the MB feedback data written from a superior controller/SCADA to the ECpv2 proprietary modbus map page 3.

kW origin determines from where to retrieve/calculate the grid power production. Supported methods are:

1. Mains meter.
2. Modbus page 03.
3. PV Comm.

#### *Mains meter*

Up to 16 power meters for sensing grid production can be installed. ECpv2 will summarize the contributions from each of the meters into one common total for the grid power being imported/exported.

### *Modbus page 03*

This will have ECpv2 use the grid power data written from a superior controller/SCADA to the ECpv2 proprietary modbus map page 3.

### *PV Comm.*

Some vendors' inverters / inverter managers support data acquisition from a power meter installed at the grid connection. The ECpv2 will acquire the active and reactive power readings from this meter via the PV communication.

kWh origin determines from where to retrieve/calculate the grid energy imported and exported. Supported methods are:

1. ECpv2.
2. Power meters

### *ECpv2*

Based on the kW measured, the ECpv2 integrates energy counters itself.

### *Power meters*

The ECpv2 will read the total energy counter from the power meters and summarize those.

ECpv2 will, based on this, derive daily, monthly and yearly energy counters.

The meter used must provide both the total energy export counter and the total energy import counter in order to make use of this approach. Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various meter models.

<http://www.encombi.com/products/ECpv2/>

Note that all counters derived from energy counters remain linked to the ECpv2 energy counters still.

### *References*

On the same submenu level the setup page for References is found. Clicking the up/down arrows will lead to it.

## References

Mains P ctrl:	FIXED P
PREF:	20.0 kW
Mains Q ctrl:	FIXED Q
QREF:	0.0 kVAr
COSPHIREF:	1.000
Sensing method:	SUM ALL PHASES
<b>Measurement</b>	
MB Feedb. origin:	FIXED ON
kW Origin:	MAINS METER
kWh Origin:	ECPV



**Mains reference setup page.**  
References applies when running parallel to utility.

**Mains P ctrl determines the active power regulation scheme.**  
Fixed P: the device will keep the active PV power production fixed.  
Fixed P PCC: device will keep the active power production fixed at point of connection to utility.  
PREF is used as reference by the Mains P ctrl scheme.

**Mains Q ctrl determines the reactive power regulation scheme.**  
Fixed Q: the device will keep the reactive PV power production fixed.  
Fixed Q PCC: device will keep the reactive power production fixed at point of connection to utility.  
Fixed cosphi C or Fixed cosphi I: the device will keep the cosphi of the PV plant fixed running capacitive and inductive respectively.  
Fixed cosphi C PCC or Fixed cosphi I PCC: the device will keep the cosphi at point of connection to utility fixed, capacitive and inductive respectively.  
QREF and COSPHIREF are used as references by the Mains Q ctrl scheme.

**Sensing method determines if to base reference on the sum of all phases, 3 x lowest loaded phase or 3 x sensing values.**

**MB feedback origin determines from which source the mains breaker position feedbacks arises.**

**kWh origin determines from which source the mains energy production arises.**

2021-01-05-15:04:51

Mains P ctrl determines the active power regulation scheme.

- Fixed P: the device will keep the active PV power production fixed.
- Fixed P PCC: device will keep the active power production fixed at the point of connection to utility. This is therefore to be the selected method for doing self consumption / zero export operation.

PREF is used as the reference setting by the Mains P ctrl scheme.

Mains Q ctrl determines the reactive power regulation scheme.

- Fixed Q: the device will keep the reactive PV power production fixed.
- Fixed Q PCC: device will keep the reactive power production fixed at the point of connection to utility.
- Fixed cosphi C or Fixed cosphi I: the device will keep the cosphi of the PV plant fixed running capacitive and inductive respectively.
- Fixed cosphi C PCC or Fixed cosphi I PCC: the device will keep the cosphi at point of connection to utility fixed, capacitive and inductive respectively.

QREF and COSPHIREF are used as reference settings by the Mains Q ctrl scheme.

Sensing method determines what power readings to base the calculated references upon. Three options are available.

1. Sum all phases.
2. 3 x lowest phase.
3. 3 x sensing.

#### *Sum all phases*

The control will work on the total loading of all phases not regarding any potential asymmetry. Using this method with asymmetrical loads can in a self consumption situation for instance result in a situation where the net power feed to grid is in fact 0kW but there is import on some phase(s) and export on other phase(s).

#### *3 x lowest phases*

The control will identify the least loaded phase and multiply this with three. This can be useful when load is asymmetrical avoiding the situation described above. The net import power from the grid may not be 0kW but exporting power on any of the three phases are avoided.

#### *3 x sensing*

This can be used when load is symmetrical. Only one CT is installed, sensing the load from one phase only. The phase load sensed is being representative for the loading on the other two phases. The ECpvh will multiply the load sensed with three in order to get the total load.

MB feedback origin determines from which source the mains breaker position closed feedbacks arises.

- Fixed on.
- Power meter.
- EClogic.
- All GB off
- Modbus page 03.

### *Fixed on*

In case of sites without gensets where ECpvh is used for self consumption operation alone for example, the mains breaker position can always be assumed to be closed.

### *Power meter*

In case a power meter is used the input1 of the power meter will be interpreted as mains breaker closed feedback.

### *EClogic*

In more complex electrical infra structures having for instance sectional breakers separating the utility from the PV plant, a condition of whether the utility is at all connected to the same AC busbar section as the PV needs to be taken into consideration. Such conditions can be customized from within EClogic.

### *All GB off*

In case all GBs are off and there is no genset communication alarm present, the ECpvh will interpret this as the mains breaker position is closed.

### *Modbus page 03*

This will have ECpvh use the MB feedback data written from a superior controller/SCADA to the ECpvh proprietary modbus map page 3.

kW origin determines from where to retrieve/calculate the grid power production. Supported methods are:

1. Mains meter.
2. Modbus page 03.
3. PV Comm.

### *Mains meter*

Up to 16 power meters for sensing grid production can be installed. ECpvh will summarize the contributions from each of the meters into one common total for the grid power being imported/exported.

### *Modbus page 03*

This will have ECpvh use the grid power data written from a superior controller/SCADA to the ECpvh proprietary modbus map page 3.

### *PV Comm.*

Some vendors inverters / inverter managers support data acquisition from a power meter installed at the grid connection. The ECpvh will acquire the active and reactive power readings from this meter via the PV communication.

kWh origin determines from where to retrieve/calculate the grid energy imported and exported. Supported methods are:

1. ECpvh.
2. Power meters

### ECpvh

Based on the kW measured, the ECpvh integrates energy counters itself.

### Power meters

The ECpvh will read the total energy counter from the power meters and summarize those.

ECpvh will, based on this, derive daily, monthly and yearly energy counters.

The meter used must provide both the total energy export counter and the total energy import counter in order to make use of this approach. Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various meter models.

<http://www.encombi.com/products/ECpvh/>

Note that all counters derived from energy counters remain linked to the ECpvh energy counters still.

### API

On the same submenu level the setup page for API setup is found. Clicking the up/down arrows will lead to it.

ENcombi

ADMIN

API

Enable: DISABLED

API command support setup page.  
The ECpv2 can take various commands via ECapi including active and reactive power references for PV.  
Here it is enabled if to take commands from ECapi.  
Consult the ECapi documentation on which commands are supported and how to apply them.

2024-08-21-13:28:57

The ECpv2 can take in various commands including power and reactive power commands for PV via ECapi. This enables an online optimizer service provider to control the PV via ECapi thereby eliminating the need for installing any additional HW on site. The API setting must be enabled in order to have the ECpv2 accepting commands applied via ECapi. Consult the ECapi documentation on which commands are available and how to apply them.

## Tariffs

On the same submenu level the setup page for utility tariffs are found. Clicking the up/down arrows will lead to it.

**ENcombi** ADMIN

**Tarif**

Import: 0.08 Euro/kWh

Export: 0.02 Euro/kWh

**Mains tariff setup page.**  
 Import is used for calculating expense for the energy imported by the utility as well as for the import savings generated by the PV plant.  
 Export is used for calculating earnings for the energy exported to the utility.

2021-01-05-15:06:26

Import is used for calculating expense for the energy imported by the utility as well as for the import savings generated by the PV plant.

Export is used for calculating earnings for the energy exported to the utility.

## Rated sizes

On the same submenu level the setup pages for gensets rated power are found. Clicking the up/down arrows will lead to them.

**ENcombi** ADMIN

**Rated**

Mains 1: 100.0 kW

Mains 2: 100.0 kW

Mains 3: 100.0 kW

Mains 4: 100.0 kW

Mains 5: 100.0 kW

Mains 6: 100.0 kW

Mains 7: 100.0 kW

Mains 8: 100.0 kW

**Mains capacity setup page.**

2021-01-05-15:06:43

A total of 16 utility connections are supported. Above page is one of two pages available for setting up the rated mains trafo sizes.

## Counters

On the same submenu level pages for various utility related counters are found. Clicking the up/down arrows will lead to them.

- Imported energy (daily, monthly, yearly and total).
- Exported energy (daily, monthly, yearly and total).
- Import expense (daily, monthly, yearly and total).
- Export revenue (daily, monthly, yearly and total).

Below is an example.

**ENcombi** ADMIN

Imported	Active	Update	
ACE:	0 kWh	250 kWh	<input checked="" type="checkbox"/>
ACE YEAR:	0 kWh	200 kWh	<input checked="" type="checkbox"/>
ACE MONTH:	0 kWh	210 kWh	<input checked="" type="checkbox"/>
ACE DAY:	0 kWh	160 kWh	<input checked="" type="checkbox"/>
Exported	Active	Update	
ACE:	0 kWh	0 kWh	<input checked="" type="checkbox"/>
ACE YEAR:	0 kWh	0 kWh	<input checked="" type="checkbox"/>
ACE MONTH:	0 kWh	0 kWh	<input checked="" type="checkbox"/>
ACE DAY:	0 kWh	0 kWh	<input checked="" type="checkbox"/>

Mains import/export counters preset page. Counters with checkmark in the update column will be preset with keyed in value when save button is pressed. Toggle between checkmark and crossmark by pressing the button.

2021-01-05-15:23:35

The counters will be incremented automatically by the ECpvh in accordance with operation conditions. The counters are part of the counters backup discussed in the Identifier chapter.

The menus are only providing the possibility for manually presetting of the counters. Counters with a check mark in the update column will be preset with the keyed in value when the save button is pressed. Toggle between check mark and cross mark by pressing the respective button.

## Meter

Clicking the power meter button on the right hand side of any of the above pages leads to mains meter configuration. The mains meter configuration is done in the exact same manner as the already covered PV power meter configuration. Refer to PV power meter configuration for setting up of power meters.

## Grid support

Clicking the grid support button on the right hand side of any of the above pages leads to grid support configuration.

### Grid support P(f)

On the same submenu level the setup page for frequency support is found. Clicking the up/down arrows will lead to it.

#### Grid support P(f)

Deadband low:	49.00 Hz
Slope low:	10.00 kW/Hz
Cutoff low:	48.00 Hz
Deadband high:	51.00 Hz
Slope high:	-10.00 kW/Hz
Cutoff high:	52.00 Hz
Enable:	DISABLED



P(f) grid support setup page.  
 When grid frequency is within defined deadband the power reference is unaffected by the grid support.  
 When frequency goes above or below the deadband the reference is set equal to the PV power at that instance. The reference is then altered according to the frequency and the respective slopes. Frequencies above or below cutoff thresholds do not contribute to further alteration.  
 Once frequency returns within the defined deadband, the references are again passed by without interference from the grid support.

When the grid frequency is within the defined deadband the power reference is unaffected by the grid support. When frequency goes above or below the deadband the reference is set equal to the PV power at that instance. The reference is then altered according to the frequency and the respective slopes. Frequencies above or below cutoff thresholds do not contribute to further alteration.

Once frequency returns within the defined deadband, the references are again passed by without interference from the grid support. Note that when grid power origin is set to "Mains meter" the Line1 frequency needs to be part of the data read from the mains meter in order to use the frequency support. Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various meter models.

<http://www.encombi.com/products/ECpvh/>

## Grid support U(Q)

On the same submenu level the setup page for frequency support is found. Clicking the up/down arrows will lead to it.

ENcombi

ADMIN

## Grid support Q(U)

Deadband low:	390.0 V
Slope low:	10.00 kVar/V
Cutoff low:	380.0 V
Deadband high:	410.0 V
Slope high:	-10.00 kVar/V
Cutoff high:	420.0 V
Enable:	DISABLED



Q(U) grid support setup page.  
 When grid voltage is within defined deadband the reactive power reference is unaffected by the grid support.  
 When voltage goes above or below the deadband the reference is set equal to the PV reactive power at that instance.  
 The reference is then altered according to the voltage and the respective slopes. Voltages above or below cutoff thresholds do not contribute to further alteration.  
 Once voltage returns within the defined deadband, the references are again passed by without interference from the grid support.

2024-08-21-13:31:41

When the grid voltage is within a defined deadband the reactive power reference is unaffected by the grid support. When voltage goes above or below the deadband then the reference is set equal to the PV reactive power at that instance. The reference is then altered according to the voltage and the respective slopes. Voltages above or below cutoff thresholds do not contribute to further alteration.

Once voltage returns within the defined deadband, the references are again passed by without interference from the grid support. Note that when grid power origin is set to "Mains meter" that Line1-Line2 voltage needs to be part of the data read from the mains meter in order to use the voltage support. Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various meter models.

<http://www.encombi.com/products/ECpvh/>

## Load

Clicking the sensor button leads to the following page.

ENcombi ADMIN

Load power meter

DG load meter: 0

PV load meter: 0

Mains load meter: 0

Load power meter setup page.  
 A maximum of 16 power meters for load is supported.  
 The load power meter share the ID range with PV, DG or Mains.  
 The sum of load meter + source can be maximum 16.  
 The load power meter will use the same protocol as the source.  
 If DG protocol is selected, the load meter will use the same protocol.

2022-03-14-11:34:43

Above page there are 3 options to select load power meters. If the DG load meter is selected, the power meter protocol is selected on the DG power meter page. The ID of the load meter will be the next ID after the DG power meter.

If selecting PV or mains load meter, it is the same philosophy. The protocol is selected on the DG, PV or mains power meter setup page.

*Example with same power meter model:*

2 x DG power meters with ID 3 and 4.

1 x load power meter with ID 5.

Under the DG power meter setup page the specific power meter protocol is selected and ID 3 is set as ID and the number of power meters is set to 2.

Then the user needs to select 1 load power meter on DG load meter. Then the user are able to see data from alle 3 power meters, but the first 2 power meters are from DG and the third is from load meter.

*Example with different power meter models:*

2 x DG power meters with ID 3 and 4.

1 x load power meter with ID 5.

Under the DG power meter setup page the specific power meter protocol is selected and ID 3 is set as ID and the number of power meters is set to 2.

The load power meter is another protocol than the DG power meter protocol, so the user will need to configure a PV power meter with the correct protocol. On the setup page the user will type in 0 as the number of PV power meters and the ID must be the load power meter ID, which is 5.

Then go to the load power meter setup page and select 1 meter at PV load power meter.

## Load meter for control

Clicking the Advanced button to the right hand side will lead to the menu below.

ENcombi ADMIN

Load power meter

DG calc.	DISABLED
Grid calc.	DISABLED

**Load meter control setup page.**  
 Per default the system measures the production of the sources, calculates the total load consumption based and bases its control on that. It is possible to do the opposite and have the system use the load meter readings instead to calculate the source power.  
 If for instance the load is measured instead of the power at the grid connection point then when the system is connected to grid the power at the grid connection point can be calculated.

2022-04-06-10:30:09

Normally the total load in the system is a calculated value based on the production of the various sources (genset, PV, grid and battery) and the control is based on the readings from the sources directly. On this page it is possible to have the ECpv2X use the readings from the load meters as an expression of the total loading in the system and use this for calculating the power flowing in/out of the grid when being parallel to the grid and the power production of the genset when being parallel to the genset respectively and do its control based upon that instead.

This can be useful in the various cases where for instance the grid meters can't be mounted due to physical constraints and only load meters are available or it could be a simple ATS application with one genset and one grid, then the control can be base on a single meter placed on the load side of the ATS instead of having both a power meter for the genset and a power meter for the grid.

## Sensors

Clicking the sensor button leads to the following page.

The screenshot shows the 'Sensors' configuration page in the ENcombi interface. The page title is 'Sensors' and the user is logged in as 'ADMIN'. A table lists various meteorological sensors, all of which are currently set to 'OFF'. The sensors listed are: POA origin, BOM origin, GHI origin, Amb. temp. origin, Wind speed origin, RH origin, Bar. press. origin, Wind dir. origin, and Rain origin. In the center of the page, there is a callout box with a pencil icon and a double-headed arrow icon. The text in the callout box reads: 'Meteorological setup page. Select the origin of the various meteorological readings. They origin can be from one of the sensors installed or directly from the PV communication.' To the right of the callout box, there is a red upward-pointing arrow icon. At the bottom right of the page, the timestamp '2020-07-10-13:41:50' is displayed.

Sensors	
POA origin:	OFF
BOM origin:	OFF
GHI origin:	OFF
Amb. temp. origin:	OFF
Wind speed origin:	OFF
RH origin:	OFF
Bar. press. origin:	OFF
Wind dir. origin:	OFF
Rain origin:	OFF

Meteorological setup page.  
Select the origin of the various meteorological readings.  
They origin can be from one of the sensors installed or directly from the PV communication.

2020-07-10-13:41:50

The screenshot shows the 'Sensors' configuration page in the ENcombi interface, specifically for fuel level readings. The page title is 'Sensors' and the user is logged in as 'ADMIN'. A table lists four fuel level sensors, all of which are currently set to 'OFF'. The sensors listed are: Fuel Lvl 01 origin, Fuel Lvl 02 origin, Fuel Lvl 03 origin, and Fuel Lvl 04 origin. In the center of the page, there is a callout box with a pencil icon and a double-headed arrow icon. The text in the callout box reads: 'Fuel level setup page. Select the origin of the various fuel level readings. They origin can be from one of the sensors installed, directly from the PV communication or by Modbus Page 3.' To the right of the callout box, there is a red upward-pointing arrow icon. At the bottom right of the page, the timestamp '2022-03-14-11:51:39' is displayed.

Sensors	
Fuel Lvl 01 origin:	OFF
Fuel Lvl 02 origin:	OFF
Fuel Lvl 03 origin:	OFF
Fuel Lvl 04 origin:	OFF

Fuel level setup page.  
Select the origin of the various fuel level readings.  
They origin can be from one of the sensors installed, directly from the PV communication or by Modbus Page 3.

2022-03-14-11:51:39

Above page holds the list of all meteorological readings supported. The origin of these readings can be selected as either Modbus RTU based sensors, inverter communication, Modbus page 3 or by EClogic.

### Modbus RTU Sensors

On the same submenu level the page for setting up Modbus RTU sensor communication is found. Clicking the up/down arrows will lead to it.

### Sensors

COM port:	COM2
Sensor 1:	OFF
Sensor 1 ID:	1
Sensor 2:	OFF
Sensor 2 ID:	1
Sensor 3:	OFF
Sensor 3 ID:	1
Sensor 4:	OFF
Sensor 4 ID:	1



Sensor setup page.  
Sensor communication is running Modbus RTU only.  
Whether to use COM2 or COM3 is selectable by parameter.  
Port settings is setup at dedicated port setup page.

2020-07-10-13:42:10

Sensor communication is running Modbus RTU only. Whether to use sensors on COM2 or COM3 is selectable by parameter. A maximum of 4 Modbus RTU sensors can be connected to the ECpvh.

Check the link below to see which sensors are supported by ECpvh.

<http://www.encombi.com/products/ECpvh/>

### PV generating capacity

On the same submenu level the page for calculating the generating capacity (GC) of the PV panels is found. Clicking the up/down arrows will lead to it.

### Sensors

Panel temp. coef.:	-0.41 %/C
Degradation:	0.0 %/year
Year:	2022
DC loss:	0.0 %
Inv. efficiency:	100.0 %
AC loss:	0.0 %
GC compensation:	OFF



PV generating capacity setup page.  
Panel temperature coefficient can be keyed in.  
Based on POA and BOM, generating capacity compensation of the PV panels installed can be calculated. Furthermore can the panel degradation factor, DC loss factor, inverter efficiency and AC loss factor be keyed in to get the generating capacity on the AC side.  
The device uses the the generating capacity on the AC side for handling curtailment counters and PV performance ratios. In case generating capacity compensation is not enabled, installed PV panel capacity will be used as PV generating capacity by device.

2022-07-11-13:53:21

GC compensation selection determines if and how to do generating capacity compensation of the PV panels. The ECpvh uses PV panel generating capacity for handling curtailment counters and PV performance ratios. Supported methods are:

1. Disabled.
2. Sensors.

### 3. Modbus page 03.

#### *Disabled*

In this case the installed PV panel capacity will be used as PV generating capacity by the ECpvh.

#### *Sensors*

Based on the keyed in Installed capacity and Panel temperature coefficient and the readings from the POA and BOM sensors, the generating capacity of the PV panels is calculated. The efficiency of the inverters is thereafter included to get the PV generating capacity.

#### *Modbus page 03*

This will have ECpvh use the PV generating capacity data written from a superior controller/SCADA to the ECpvh proprietary modbus map page 3.

#### *EClogic*

In EClogic it is possible to use the dedicated EClogic pages to setup the input to the data points.

## IO modules

Clicking the IO module button leads to the following page.

**ENcombi** VIEWER

**IO modules**

COM port:	COM2
IO 1:	OFF
IO 2:	OFF
IO 3:	OFF
IO 4:	OFF

IO module setup page.  
 IO module communication can either run Modbus RTU or Modbus TCP.  
 Whether to use COM2, COM3 or TCP is selectable by parameter.  
 Port settings is setup at dedicated port setup page.

2021-01-22-17:11:09

Above page holds the setting up Modbus IO module communication. IO module communication is running either Modbus RTU or Modbus TCP. Whether to use IO modules on COM2, COM3 or TCP is selectable by parameter. A maximum of 4 Modbus IO modules can be connected to the ECpvh. The ECpvh can also read IO data directly from another ECpvh. This is selectable by parameter.

Check the link below to see which IO modules that are supported by ECpvh.

<http://www.encombi.com/products/ECpvh/>

Clicking the up/down arrows leads to the page below where the Modbus ID and IP addresses for the respective IO modules are set up.

**ENcombi** ADMIN

**IO modules**

IO 1 ID:	1
IO 1 IP:	192.168.1.50
IO 2 ID:	1
IO 2 IP:	192.168.1.50
IO 3 ID:	1
IO 3 IP:	192.168.1.50
IO 4 ID:	1
IO 4 IP:	192.168.1.50


IO module setup page.  
 Modbus RTU ID of the IO modules is selectable by parameter.  
 Modbus TCP IP of the IO modules is selectable by parameter.  
 The Modbus ID selected is used in the TCP frames.

2021-01-24-11:56:05

## Analogue input/output

The ECpvH supports analogue input/output modules. When the analogue module is selected in the IO window setup, all settings are placed in the monitoring of the IO module.

ENcombi



When pressing the IO button, it will lead to the following page.

ENcombi

IO modules	IO type	IO inputs	IO outputs	Communication state:	Communication enable:
IO 1:	EX04AIO	N.A	N.A		
IO 2:	EX04AIO	N.A	N.A		
IO 3:	EX1608DD	0011 0000 0000 1100	0000 0000 0000 0000		
IO 4:	EX04AIS	N.A	N.A		

From this page it is possible to select which IO module to set up and monitor values. If the IO module is digital input/output, it is not possible to click on the module, the actual bit value is present at this page. By clicking on the IOx module, it will lead to the following page.

IO2	AIO type	Value	PCT	Minimum Scale	Maximum Scale	State:
Channel 1:	INPUT	1500.0	36.6 %	0.0	4095.0	Normal
Channel 2:	INPUT	2000.0	48.8 %	0.0	4095.0	Normal
Channel 3:	OUTPUT	0.0	0.0 %	0.0	4095.0	Normal
Channel 4:	OFF	N.A	N.A	0.0	4095.0	N.A



Module temp: 32.2 C

Communication state:

2022-02-07-14:16:54

From this page it is possible to scale the input/output on each channel of the IO module. The input value can be used for Pref, Qref or other data points. This is set in EClogic. The value shown is the scaled value and the percentage is the percentage of the range from 0-100%. The maximum range is 0-4095. The module temperature is shown in the lower right corner and the state of each channel can be read to the right.


## Alarms

Clicking the alarm button leads to menus of customizable alarms.

- Genset low power.
- Mains low power.
- COM2 port slave alarm.
- COM3 port slave alarm.
- TCP port slave alarm.


Other alarms exist as well but they are not customizable alarms as the ones listed above.


### Genset low power


ADMIN

---

DG low P	
Threshold:	-5 %
Delay:	5.0 s
Enable:	DISABLED
Signal:	DISABLED
Action:	NOTIFICATION
Auto ack.:	DISABLED





Genset low power alarm setup page.  
 When genset power is below the threshold the alarm condition is present.  
 When condition has been present for a periode equal to or longer than the delay and in case the alarm is enabled the alarm is provoked.  
 When alarm is provoked, the signal selected will be activated and the action selected will be taken.  
 The alarm is automatically acknowledged in case auto ack. is enabled.

2020-07-10-13:49:26

When the genset power is below the threshold the alarm condition is present. When the condition has been present for a period equal to or longer than the delay and in case the alarm is enabled the alarm is provoked. When the alarm is provoked, the signal selected will be activated and the action selected will be taken. The alarm is automatically acknowledged in case auto ack. is enabled.

Signals available:

1. Relay01 on all PV meters
2. Relay02 on all PV meters
3. Relay01 on all genset meters
4. Relay02 on all genset meters
5. Relay01 on all mains meters
6. Relay02 on all mains meters

If to activate a relay on a specific meter only, then this can be made through ELogic.

Actions available:

1. Notification
2. Soft stop
3. Hard stop

Notification means populating an alarm and creating a log entry.

Soft stop and Hard stop will besides the notification also stop down the PV plant. That being with power ramp down and without power ramp down respectively.

## Mains low power

ENcombi

ADMIN

### Mains low P

Threshold:	-5 %
Delay:	5.0 s
Enable:	DISABLED
Signal:	DISABLED
Action:	NOTIFICATION
Auto ack.:	DISABLED



Mains low power alarm setup page.  
 When mains power is below the threshold the alarm condition is present.  
 When condition has been present for a periode equal to or longer than the delay and in case the alarm is enabled the alarm is provoked.  
 When alarm is provoked, the signal selected will be activated and the action selected will be taken.  
 The alarm is automatically acknowledged in case auto ack. is enabled.

2020-07-10-13:49:45

When the mains power is below the threshold the alarm condition is present. When the condition has been present for a period equal to or longer than the delay and in case the alarm is enabled the alarm is provoked. When the alarm is provoked, the signal selected will be activated and the action selected will be taken. The alarm is automatically acknowledged in case auto ack. is enabled.

## COM2 slave

ENcombi

ADMIN

### COM2 slave

Delay:	5.0 s
Enable:	DISABLED
Signal:	DISABLED
Action:	NOTIFICATION
Auto ack.:	DISABLED



COM2 slave alarm setup page.  
 When no frames are received from modbus master the alarm condition is present.  
 When condition has been present for a periode equal to or longer than the delay and in case the alarm is enabled, the alarm is provoked.  
 When alarm is provoked, the signal selected will be activated and the action selected will be taken.  
 The alarm is automatically acknowledged in case auto ack. is enabled.



2020-07-10-13:50:04

When no frames are received from modbus master the alarm condition is present. When the condition has been present for a period equal to or longer than the delay and in case the alarm is enabled, the alarm is provoked. When the alarm is provoked, the signal selected will be activated and the action selected will be taken. The alarm is automatically acknowledged in case auto ack. is enabled.

## COM3 slave

ENcombi

ADMIN

### COM3 slave

Delay:	5.0 s
Enable:	DISABLED
Signal:	DISABLED
Action:	NOTIFICATION
Auto ack.:	DISABLED



COM3 slave alarm setup page.  
 When no frames are received from modbus master the alarm condition is present.  
 When condition has been present for a periode equal to or longer than the delay and in case the alarm is enabled, the alarm is provoked.  
 When alarm is provoked, the signal selected will be activated and the action selected will be taken.  
 The alarm is automatically acknowledged in case auto ack. is enabled.



2020-07-10-13:50:21

When no frames are received from modbus master the alarm condition is present. When the condition has been present for a period equal to or longer than the delay and in case the alarm is enabled, the alarm is provoked. When the alarm is provoked, the signal selected will be activated and the action selected will be taken. The alarm is automatically acknowledged in case auto ack. is enabled.

## TCP slave

ENcombi

ADMIN

### TCP slave

Delay:	5.0 s
Enable:	DISABLED
Signal:	DISABLED
Action:	NOTIFICATION
Auto ack.:	DISABLED



TCP slave alarm setup page.  
 When no frames are received from modbus master the alarm condition is present.  
 When condition has been present for a periode equal to or longer than the delay and in case the alarm is enabled, the alarm is provoked.  
 When alarm is provoked, the signal selected will be activated and the action selected will be taken.  
 The alarm is automatically acknowledged in case auto ack. is enabled.

2020-07-10-13:50:43

When no frames are received from modbus master the alarm condition is present. When the condition has been present for a period equal to or longer than the delay and in case the alarm is enabled, the alarm is provoked. When the alarm is provoked, the signal selected will be activated and the action selected will be taken. The alarm is automatically acknowledged in case auto ack. is enabled.

## Fuel level alarm

ENcombi

ADMIN

## Fuel Level alarm

Threshold:	20 %
Delay:	5.0 s
Enable:	DISABLED
Signal:	DISABLED
Action:	NOTIFICATION
Auto ack.:	DISABLED



Fuel level alarm setup page.  
 When Fuel level goes below the threshold the alarm condition is present.  
 When condition has been present for a periode equal to or longer than the delay and in case the alarm is enabled the alarm is provoked.  
 When alarm is provoked, the signal selected will be activated and the action selected will be taken.  
 The alarm is automatically acknowledged in case auto ack. is enabled.

2022-03-14-12:00:09

When fuel level goes below the threshold, the alarm conditions are present. When the condition has been present for a period equal to or longer than the delay and in case the alarm is enabled, the alarm is provoked. When the alarm is provoked, the signal selected will be activated and the action selected will be taken. The alarm is automatically acknowledged in case auto ack. is enabled.

## Common master communication

ENcombi

ADMIN

## Comm alarm

Delay:	60.0 s
Enable:	ENABLED
Signal:	DISABLED
Action:	NOTIFICATION
Auto ack.:	ENABLED



Common modbus master communication alarm setup page.  
 When any modbus master communication alarm is triggered, then the alarm condition is present.  
 When the condition has been present for a periode equal to or longer than the delay, and in case the alarm is enabled, the alarm is provoked.  
 When the alarm is provoked, the signal selected will be activated and the action selected will be taken.  
 The alarm is automatically acknowledged in case auto ack. is enabled.

2022-03-10-10:13:08

This alarm condition is present in case any of the modbus master communication alarms for the inverter, power meter, sensor or IO communication are raised. When the condition has been present for a period equal to or longer than the delay and in case the alarm is enabled, the alarm is provoked. When the alarm is provoked, the signal selected will be activated and the action selected will be taken. The alarm is automatically acknowledged in case auto ack. is enabled.

## Modbus Master comm. alarms

ENcombi

ADMIN

## Master alarms

Power meter:	10
Inverter:	10
Sensor:	10
IO:	10




Modbus master communication alarm setup page.  
The number of timeouts to encounter before the respective alarm is raised can be set here. This way the sensitivity of the various Modbus Master related communication alarms can be adjusted. Mail and FTP transfer are suppressed in case the respective timeout is set lower than the value of 10.

2022-10-31-17:49:53

Here the sensitivity of the Modbus Master communication alarms can be adjusted. The settings dictates the number of timeouts to encounter before the respective Modbus Master alarm is raised.

## Overview

When all settings are made clicking the overview button leads to the below page providing a quick overview of the configuration made including protocols, baud rates, IDs/IPs selected for inverter, meters and sensors etc.





## Nighttime

Clicking the Nighttime button leads to the page below where the nighttime period can be defined.

ENcombi ADMIN

---

Night time

Start hour:	18 h		
Start minute:	0 min	<p>Night time setup page. Here the night time period can be defined using the night time start and night time stop settings.</p>	
Stop hour:	6 h		
Stop minute:	0 min		

2020-07-10-13:51:58

Whether nighttime or daytime period is active can be used for switching the P/Q priority of the PV plant for instance.

## Simulation



Clicking the simulation button leads to the page below where the simulation mode can be enabled/disabled.

ENcombi ADMIN

---

Simulation

Simulation: ENABLED

Simulation setup page.

Simulation enables you to try out the ECpv in an office environment without the need of being connected to any real equipment. When simulation is enabled a button will appear on the overview page. Here various stimuli like active and reactive loads can be applied. Run through the various control schemes and see their behaviour. Check out how data on plant level to component level is visualised.

Additional settings required when using simulation:

- 1) GB feedback origin: Meter communication.
- 2) Gesent kW origin: Genset Meter.
- 3) MB feedback origin: Meter communication.
- 4) Mains kW origin: Mains meter.
- 5) PV kW origin: PV meter or Inverter Acquisition.
- 6) Inverter control: Enable.
- 7) Inverter acquisition: Enable.

Communication towards power meters, inverters etc. must be disabled. The number of power meters and inverters selected will however reflect on the visualization as in real operation. Also the rated size set up for the PV plant, genset etc. will have the normal impact.

2020-07-10-13:52:18

Simulation enables you to try out the ECpvh in an office environment without the need of being connected to any real equipment. When simulation is enabled a button will appear on the monitoring overview page. Here various stimuli like active and reactive loads can be applied. Run through the various control schemes and see their behaviour. Check out how data on plant level to component level is visualised.

Additional settings required when using simulation:

- 1) GB feedback origin: Meter communication.
- 2) Gesent kW origin: Genset Meter.
- 3) MB feedback origin: Meter communication.
- 4) Mains kW origin: Mains meter.
- 5) PV kW origin: PV meter or Inverter Acquisition.
- 6) Inverter control: Enable.
- 7) Inverter acquisition: Enable.

Furthermore, communication towards power meters, inverters etc. must be disabled. The number of power meters and inverters selected will however reflect on the visualization as in real operation. Also the rated size set up for the PV plant, genset etc. will have the normal impact.

## Proprietary modbus pages

Clicking the pages button leads to the following page.

ENcombi ADMIN

Pages

SunSpec slave:	DISABLED
Proprietary slave:	ENABLED
Page 1:	ENABLED
Page 2:	ENABLED
Page 3:	DISABLED
Page 4:	ENABLED
Page 5:	DISABLED

Modbus slave page config.

In case SunSpec slave is enabled, the device will accept references received from a SunSpec master.

In case Proprietary slave is enabled, the device will accept references etc. received from a Modbus master. The individual proprietary pages can be enabled here. Consult the Modbus Slave documentation to learn the content of each page.

2021-03-28-14:11:01

In case SunSpec slave is enabled, the ECpvh will accept references received from a SunSpec master. In case disabled the reference will be generated by the ECpvh's own setup found under genset or mains settings depending on whether parallelling to genset or mains is ongoing.

In case Proprietary slave is enabled, the ECpvh will accept instructions to be received over modbus via a dedicated proprietary modbus profile. The various instructions are furthermore grouped together in different pages that need to be enabled individually. Consult the Modbus slave documentation on ENcombi website for detailed information about the proprietary modbus profile.

<http://www.encombi.com/products/ECpvh/>

## Monitoring

Clicking the monitoring button leads to the following page.

## Monitoring

Monitoring Total

DISABLED



Monitoring setup page.  
Monitoring on ECweb will per default only display the Genset and Grid power and the Load consumption that is connected to the same busbar as the PV. The same applies for the Modbus and subsequently the ECpanel and ECcloud. Also the energy counters and its derivatives will only increment based on the Genset and Grid power generated when connected to the same busbar as the PV. With the designated setting this can be changed so the total values measured are used instead throughout it all.

2023-05-23-11:55:25

Monitoring on ECweb will by default only display the Genset and Grid power and the Load consumption that is connected to the same busbar as the PV. The same applies for the Modbus and subsequently the ECpanel and ECcloud. Also the energy counters and its derivatives will only increment based on the Genset and Grid power generated when connected to the same busbar as the PV. With the designated "Monitoring total" setting this can be changed so the total values measured are used instead throughout it all.

## Logs

The ECpvh offers logging both locally on SD-card or USB-stick and as time series data pushed to an online database.

### Local logs with transmission via mail/ftp

The ECpvh features logging stored locally on SD-card or on USB stick.  
The ECpvh can make three different logs:

- Event log
- Summary log
- Production log

The logs are stored locally on ECpvh; either on SD-card or on USB-stick.

ENcombi ADMIN

---

**Log config**

Log drive:	SD-card
Event log:	ENABLED
Summary log:	ENABLED
Production log:	ENABLED
Log rate:	5 min

Log setup page.  
 USB-key or SD-card can be used for logging.  
 Use of USB-key recommended to avoid wearing SD-card.  
 Three logs can be enabled/disabled independently.  
 Event-log holds events and alarms.  
 Summary-log holds the result of a days production.  
 Production-log holds fixed interval loggings  
 of production during a day.  
 The logs can be read directly on web server  
 as well as be transmitted via ftp or mail.  
 Selected storage media must hold a "Logs" folder in the root directory.

Event log:	<input type="text" value="80"/>		
Summary log:	<input type="text" value="502"/>		
Production log:	<input type="text" value="551"/>		

2020-07-10-13:53:41

A new Event log is generated every day. The event log holds entries of any events taking place or any occurrences of alarms on that particular day. All entries are time stamped. The ECpvh can be set up to notify by email when a new entry is made in the event log. The ECpvh will in the text include the six most recent entries in the log.

A summary log is generated at midnight when the result of the past day is known. The log holds information about PV energy produced, revenue generated etc. The ECpvh can be set up to send the summary logs to a mail recipient automatically or transferred to an FTP server automatically. The transmission will occur at midnight when a summary log is generated.

A production log is generated at midnight when a new day has started. The following midnight when the day has passed the log is completed. The log holds time-series of PV

production, Mains power etc. The time interval is per default 5min. The ECpvh can be set up to send the production logs to a mail recipient automatically or push to an FTP server automatically. The transmission will occur at midnight when a production log is completed. The data in the production log is tabulator separated and can be imported and plotted easily in excel.

All three logs can be displayed directly on ECweb. Below example is of the production log and how it looks on ECweb. First page is a list of all the production logs available. Second page is showing data from one of those logs:

Time	PV[kW]	Genset[kW]	Mains[kW]	Load[kW]	PVcap[kW]	PVref[kW]	Genset[%]	POA[W/m2]	BOM[C]	Curtail Act	Start Act	GB On	MB On
00:00:51	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:06:01	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:11:04	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:16:07	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:21:09	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:26:12	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:31:14	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:36:17	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:41:20	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:46:25	0.0	0.0	0.0	0.0	100.0	0.0	0.0	1000.0	25.0	0	0	0	0
00:51:30	80.0	0.0	20.0	100.0	100.0	80.0	0.0	1000.0	25.0	1	1	0	1
00:56:33	80.0	0.0	20.0	100.0	100.0	80.0	0.0	1000.0	25.0	1	1	0	1
01:01:36	80.0	0.0	20.0	100.0	100.0	80.0	0.0	1000.0	25.0	1	1	0	1
01:06:39	80.0	0.0	20.0	100.0	100.0	80.0	0.0	1000.0	25.0	1	1	0	1
01:11:41	80.0	0.0	20.0	100.0	100.0	80.0	0.0	1000.0	25.0	1	1	0	1

Note that the column heading of the production log shown is not actually included in the actual file being sent by email or transferred by FTP. The files only contain the data itself.

In a similar way the Summary logs and Eventlog can be displayed.

Consult the "Control" chapter in this document for details on how to set up the various automatic file transmissions.

## Log to MySQL database

The ECpvh can push time series data to MySQL database as well. This can be to an installer/customer's own hosted database or it can be to ENcombi hosted database.

ENcombi

ADMIN

**Log config**

Host: mysqlhost.com

Database: mysql\_database

Username: mysql\_username

Password: \*\*\*\*\*

Table name: mysql\_tablename

Log rate: 5 min

Log: ENABLED

Cloud service: ENABLED

**MySQL setup page.**

When enabled, the device creates a table in the selected MySQL database should it not already be present. Afterwards the device pushes data to the table at the interval selected.

Tailor the data elements the device pushes and use your own MySQL database and preferred visualization tool. Alternatively use the Cloud service provided with the C-extra. In this case the table name and above settings are disregarded. Also the data elements pushed are fixed and can't be tailored.

In case connection to the MySQL database is lost, the device buffers data to local file and will be transferred once connection is re-established. local buffer file as well as the table in the database itself can be deleted from designated buttons.

Your device can come with free cloud service in a trial period. Below you can see if you have any free trial days available. Find the cloud service provider on the Identifiers page.

Buffer size:

Table size:

Free trial:

2020-07-10-13:55:57

When using an installer/customer hosted database the data visualization part is in the scope of the installer/customer as well. The data to push is configurable according to the MySQL documentation on ENcombi website:

<http://www.encombi.com/products/ECpvh/>

The option of using the ENcombi database requires the dedicated SW-extra "C" or time left of any complimentary free "C" trial period. The data pushed to the ENcombi database is fixed from ENcombi side and can't be tailored by installer/customer. The front-end for data visualization provided by ENcombi is called ECcloud. After the ECpvh has started pushing data to the ENcombi database the customer/installer can register it in ECcloud where data will be visualized immediately.

[www.encombi.online](http://www.encombi.online)

ENcombi  
Easy Energy Management

LOGIN

CREDENTIALS

NEW SITE

PRODUCTION LOG

LICENSE



Welcome to ECcloud

Please enter your credentials

## EClogic

EClogic provides the possibility of making project specific logical expressions when required. That could be for linking physical digital inputs applied on power meters to the position of circuit breakers or similar. Also here RRCR can be set up providing the option of a superior control system to give power references for the ECpvh to follow. First page presented when clicking the EClogic tile is the page below.

EClogic main page.

EClogic is a collection of logical features to use for site customization.

The Builder offers the possibility of logically combining various input states.  
This is done via graphical representation of logical gates.  
Say multiple breakers/contactors need to be in certain position before the PV plant is connected to Grid, this can be tailored in the Builder.  
The input to the gates are Modbus addresses and bitmasks.  
It will typically be addresses holding digital input statuses from various power meters.  
Consult the Modbus Slave documentation to identify the addresses of the inputs to use.  
Note that the default input address "0" is interpreted as "not used".  
The output of the gates are status set on dedicated Modbus addresses.  
Consult the Modbus Slave documentation to identify the addresses of the outputs generated.  
These statuses can then be used in the Linker to generate a command to the device.

The Linker offers the possibility of linking input states to commands.  
The input states are Modbus addresses and bitmasks.  
It will typically be addresses holding digital input statuses from various power meters or it can be addresses holding output status generated through the Builder.  
Consult the Modbus Slave documentation to identify the addresses of the inputs to use.  
Note that the default input address "0" is interpreted as "not used".  
The commands available are predefined commands on dedicated Modbus addresses.  
Consult the Modbus Slave documentation to identify the addresses of the available commands.

The RRCR is a dedicated configuration setup of RRCR functionality.  
16 unique Power reference levels based on 4 input combinations can be configured.



EClogic is divided into three sub categories.

1. Builder
2. Linker
3. RRCR
4. Sensor
5. IO
6. Command timers

### Builder

The Builder offers the possibility of logically combining various input states. This is done via graphical representation of logical gates. Say multiple breakers/contactors need to be in a certain position before the PV plant is connected to Grid, this can be tailored in the Builder.

The input to the gates are function code 0x04 Modbus addresses and bitmasks. It will typically be addressed holding digital input statuses from various power meters. Consult the Modbus Slave documentation to identify the addresses of the inputs to use. Note that the default input address "0" is interpreted as "not used".

The output/status of the gates are set on dedicated Modbus addresses. Consult the Modbus Slave documentation to identify the addresses of the outputs generated. These statuses can then be used in the Linker to generate a command to the device.

First page presented when clicking the builder button is the page below. Here an overview of the 16 builder lines supported is presented.

ENcombi ADMIN

The screenshot shows a grid of 16 lines, each with four gate status indicators. Line 1 has two green squares and two red squares. Lines 2 through 8 have four red squares. Lines 9 through 16 have four red squares. In the top right corner, there is an 'ADMIN' label and a red arrow icon pointing to a small diagram.

2020-07-10-14:00:11

Each builder line consists of four gates. The status of the gates are represented by the color. Red means that the gate is false and green that the gate is true.

ENcombi ADMIN

The screenshot shows the configuration for Line 1. On the left, there are three gate configurations: Gate:1 (green), Gate:2 (red), and Gate:3 (red). Each gate has an 'Address' and 'Bit' column with values 0. Gate:1 is connected to Gate:Out (green). Gate:2 and Gate:3 are also connected to Gate:Out. On the right, there is a 'Line: 1' label and a red arrow icon pointing to a small diagram.

2020-07-10-14:00:34

Clicking the line number will lead to the set up page for the specific line.

Each of the first three gates take four AND inputs and four AND NOT inputs. These three inputs are OR'ed together to generate one input to the output gate.

### Example

In the configuration shown above, address 3397 bit0 is used as input to Gate1.

From Modbus Slave documentation this is found to be input1 on PV meter1. As the input1 is active the Gate1 state is true which again results in the output gate to be true. This will generate the following statuses in the designated modbus area to go high.

ECLOGIC BUILDER AREA 1				
28000	Q1 gate output status line 1-16	16 unsigned int	bitwise	Not defined
28001	Q2 gate output status line 1-16	16 unsigned int	bitwise	Not defined
28002	Q3 gate output status line 1-16	16 unsigned int	bitwise	Not defined
28003	Q-out gate output status line 1-16	16 unsigned int	bitwise	Not defined
28004	Inverted Q-out gate output status line	16 unsigned int	bitwise	Not defined
28005...28999	RESERVED	Not defined	Reserved for later use	Not defined

Address 28000 bit0: Gate1, line1

Address 28003 bit0: Output Gate, line1

## Linker

The Linker offers the possibility of linking input states to commands. The input states are Modbus addresses and bitmasks. It will typically be addresses holding digital input statuses from various power meters or it can be addresses holding output status generated through the Builder. Consult the Modbus Slave documentation to identify the addresses of the inputs to use. Note that the default input address "0" is interpreted as "not used".

The commands available are predefined commands on dedicated Modbus addresses. Consult the Modbus Slave documentation to identify the addresses of the available commands.

First page presented when clicking the linker button is the page below. Here the 32 linker lines supported can be set up. Furthermore, the status of each link is indicated by green and red color.

INPUTS				OUTPUTS				INPUTS				OUTPUTS			
Line:	Address:	Bit:		Address:	Bit:			Line:	Address:	Bit:		Address:	Bit:		
Line:1	28003	0		29019	0			Line:17	0	0		29000	0		
Line:2	28003	0		29053	7			Line:18	0	0		29000	0		
Line:3	28003	0		29055	2			Line:19	0	0		29000	0		
Line:4	0	0		29000	0			Line:20	0	0		29000	0		
Line:5	0	0		29000	0			Line:21	0	0		29000	0		
Line:6	0	0		29000	0			Line:22	0	0		29000	0		
Line:7	0	0		29000	0			Line:23	0	0		29000	0		
Line:8	0	0		29000	0			Line:24	0	0		29000	0		
Line:9	0	0		29000	0			Line:25	0	0		29000	0		
Line:10	0	0		29000	0			Line:26	0	0		29000	0		
Line:11	0	0		29000	0			Line:27	0	0		29000	0		
Line:12	0	0		29000	0			Line:28	0	0		29000	0		
Line:13	0	0		29000	0			Line:29	0	0		29000	0		
Line:14	0	0		29000	0			Line:30	0	0		29000	0		
Line:15	0	0		29000	0			Line:31	0	0		29000	0		
Line:16	0	0		29000	0			Line:32	0	0		29000	0		

2020-07-10-14:01:41

## Example continued

In the configuration shown above address 28003 bit0 being the status of the output gate of builder line1 is used to set commands on address 29019 bit0, 29053 bit7 and 29055 bit2 respectively. From Modbus Slave documentation this is found to be the commands for:

1. Relay 1-16 on all PV meters.
2. Minimum genset load 1-8.
3. RRCR input 1-4.

















Hence activating input1 on PV meter1 have the effect of:

1. Activating relay1 on all PV meters present.
2. Overruling the parameter set under "Settings", using the Minimum genset load setting8 from EClogic instead.
3. RRCR input3 applied.

Point 2 and 3 will be explained in the following.

## Overruling of Settings parameters

On the same submenu level a set up page for overruling certain key settings is found. Clicking the up/down arrows will lead it.

Address:	Bit:	Min. genset load:	Address:	Bit:	Genset 1:
29053	0	 20.0 %	29054	0	 100.0 kW
29053	1	 30.0 %	29054	1	 100.0 kW
29053	2	 30.0 %	29054	2	 100.0 kW
29053	3	 30.0 %	29054	3	 100.0 kW
29053	4	 30.0 %	29054	4	 100.0 kW
29053	5	 30.0 %	29054	5	 100.0 kW
29053	6	 30.0 %	29054	6	 100.0 kW
29053	7	 35.0 %	29054	7	 100.0 kW

2020-07-10-14:02:26

It is currently possible to overrule:

1. Minimum genset load.
2. Genset1 rating.

From the example above it can be seen that ECpvh is now using a Minimum genset load of 35% regardless of whatever value is selected under Settings. In case the input1 on PV meter1 is removed the ECpvh will again follow the value selected under Settings. This can be useful in case gensets have different Minimum genset operating levels or if it is allowed in certain periods to operate genset(s) at a lower level.

Manipulation of the Genset1 rated power is intended for use when only one genset exists from the ECpvh point of view (one genset meter) but in fact multiple (up to 8) are present. Depending on which genset(s) are connected to the busbar the rated power is summarized accordingly by the ECpvh. This way the rated power of genset1 is dynamically adjusted by the ECpvh to match the actual combination of gensets(s) connected.

### General purpose hysteresis

On the same submenu level a set up page for general purpose hysteresis is found. Clicking the up/down arrows will lead it.



Address:	Data type:	Data sign:	Low Threshold:	High Threshold:	Output:	Set FlipFlop:	Reset FlipFlop:	Inverse:
0	16BIT	SIGNED	0.0	0.0	■	⊞	⊞	⊞
0	16BIT	SIGNED	0.0	0.0	■	⊞	⊞	⊞
0	16BIT	SIGNED	0.0	0.0	■	⊞	⊞	⊞
0	16BIT	SIGNED	0.0	0.0	■	⊞	⊞	⊞
0	16BIT	SIGNED	0.0	0.0	■	⊞	⊞	⊞
0	16BIT	SIGNED	0.0	0.0	■	⊞	⊞	⊞
0	16BIT	SIGNED	0.0	0.0	■	⊞	⊞	⊞
0	16BIT	SIGNED	0.0	0.0	■	⊞	⊞	⊞

2021-04-27-10:17:45

The value to monitor is determined by the address. The sign and data type of the value can be set. The high and low thresholds for the hysteresis can be adjusted as per the usage. Per default, the hysteresis output is latched when the value drops below the Low threshold and is cleared again when the value rises above the High threshold. In case it instead is to be latched when it rises above the High threshold and cleared when it drops below the Low threshold then this is achieved by enabling the Inverse setting. In case the value is between the Low and High thresholds, the hysteresis output can be manually latched or cleared by the Set and Reset commands. The actual state of the hysteresis output is indicated in red/green color. The hysteresis output is available in the modbus and can be used in the EClogic Builder and Linker.

## RRCR

The RRCR is a dedicated configuration setup of RRCR functionality. 16 unique power and cosphi reference levels based on 4 input combinations can be configured.

ENcombi ADMIN

4	3	2	1	Power limit:	Enable:	4	3	2	1	Power limit:	Enable:
■	■	■	■	100.0 %	DISABLED	■	■	■	■	100.0 %	DISABLED
■	■	■	■	100.0 %	DISABLED	■	■	■	■	100.0 %	DISABLED
■	■	■	■	100.0 %	DISABLED	■	■	■	■	100.0 %	DISABLED
■	■	■	■	100.0 %	DISABLED	■	■	■	■	100.0 %	DISABLED
✓	■	■	■	40.0 %	ENABLED	■	■	■	■	100.0 %	DISABLED
■	■	■	■	100.0 %	DISABLED	■	■	■	■	100.0 %	DISABLED
■	■	■	■	100.0 %	DISABLED	■	■	■	■	100.0 %	DISABLED
■	■	■	■	100.0 %	DISABLED	■	■	■	■	100.0 %	DISABLED

2020-07-10-14:03:41

ENcombi ADMIN

4	3	2	1	Cosphi ref:	Enable:	4	3	2	1	Cosphi ref:	Enable:
■	■	■	■	1.000	DISABLED	■	■	■	■	1.000	DISABLED
■	■	■	■	1.000	DISABLED	■	■	■	■	1.000	DISABLED
■	■	■	■	1.000	DISABLED	■	■	■	■	1.000	DISABLED
■	■	■	■	1.000	DISABLED	■	■	■	■	1.000	DISABLED
✓	■	■	■	1.000	DISABLED	■	■	■	■	1.000	DISABLED
■	■	■	■	1.000	DISABLED	■	■	■	■	1.000	DISABLED
■	■	■	■	1.000	DISABLED	■	■	■	■	1.000	DISABLED
■	■	■	■	1.000	DISABLED	■	■	■	■	1.000	DISABLED

2020-07-10-14:04:42

Referring to the ongoing example, as input1 on PV meter1 is active means that the RRCR input combination with only input3 being present is true. This is indicated by a check mark. As this line at the same time is enabled it causes the ECpvh to overrule whatever power reference calculated based on setup made under "Settings" and the current plant status and target the reference dictated by the RRCR instead.

## AIO

Toggle in the RRCR configuration will lead you to the following page.

ENcombi

ADMIN

Address:	Bit:	Address:	Data type:	Data sign:	Input reference	  
29065	0	0	16BIT	SIGNED	PREF	<input checked="" type="checkbox"/>
29065	1	0	16BIT	SIGNED	QREF	<input checked="" type="checkbox"/>

2022-02-01-09:46:25

It is possible to set up an input for the reference of P and Q.

If the address 29065, bit 0 and 1, is set, then the ECpvX will use the reference read from the address which is typed in. This could be AIO input.




The reference is a percentage of the rated capacity of the inverter.

## Sensor

By clicking on the sensor icon, it will lead to the following page.

ENcombi

ADMIN

Address:	Data type:	Data sign:		  
0	16BIT	SIGNED	→ POA	<input checked="" type="checkbox"/>
0	16BIT	SIGNED	→ BOM	<input checked="" type="checkbox"/>
0	16BIT	SIGNED	→ GHI	<input checked="" type="checkbox"/>
0	16BIT	SIGNED	→ Ambient Temp	<input checked="" type="checkbox"/>
0	16BIT	SIGNED	→ Wind speed	<input checked="" type="checkbox"/>
0	16BIT	SIGNED	→ RH	<input checked="" type="checkbox"/>
0	16BIT	SIGNED	→ BAR pressure	<input checked="" type="checkbox"/>
0	16BIT	SIGNED	→ Wind dir	<input checked="" type="checkbox"/>
0	16BIT	SIGNED	→ Rain	<input checked="" type="checkbox"/>

2022-03-14-12:03:13

Address:	Data type:	Data sign:		
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→	Fuel Level 01 <span style="color: red;">■</span>
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→	Fuel Level 02 <span style="color: red;">■</span>
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→	Fuel Level 03 <span style="color: red;">■</span>
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→	Fuel Level 04 <span style="color: red;">■</span>



2022-03-14-12:03:27

From here it is possible to define the address of the sensor data readings. After defining the address for the specific sensor data, it should be selected in the sensor setup to read the data from “ECLogic”.

The red indicator will change to green when selecting “ECLogic” on the setup page of sensor.

## IO

By clicking on the IO icon, it will lead to the following page.

Address:	Data type:	Data sign:	Module.Channel	Address:	Data type:	Data sign:	Module.Channel
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 1.1	0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 3.1
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 1.2	0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 3.2
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 1.3	0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 3.3
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 1.4	0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 3.4
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 2.1	0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 4.1
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 2.2	0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 4.2
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 2.3	0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 4.3
0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 2.4	0	<input type="text" value="16BIT"/>	<input type="text" value="SIGNED"/>	→ 4.4



2022-02-01-11:08:38

From here it is possible to set up which data should be linked to each output of the AIO module. All 16 outputs are present and it is possible to select which data to be sent out on each channel.

## Command timers

By clicking on the command timer icon, it will lead to the following page.

It is possible to set up 4 command timers. Type in the start day and time and stop time for the command timer. The output will be available on modbus and can be used for EClogic status/commands.

## Command panel

The command panel holds 16 configurable command buttons and 16 status indicators. By clicking on the command panel icon, it will lead to the following page where the associated text strings for the 16 buttons and indicators can be typed in.

The actual functionality of the command panel is set up in the Builder/Linker using the addresses below.

31019	BITFIELD_19	16 unsigned int	Command Panel buttons 01..16
29066	Cmd panel LED01..16: Green	16 unsigned int	bitwise
29067	Cmd panel LED01..16: Red	16 unsigned int	bitwise

## General purpose alarms

General purpose alarms enable you to trigger your own custom made alarm. Via the EClodic Builder/Linker the trigger for the alarm is set up. A total of 4 such alarms are available.

ENcombi

ADMIN

### EClodic alarm 1

Delay: 5.0 s

Signal: DISABLED

Action: NOTIFICATION

Auto ack.: ENABLED

Alarm text: EClodic AI01



EClodic alarm setup page.  
 When the EClodic alarm is triggered then the alarm condition is present.  
 The alarm is triggered from EClodic.  
 When the condition has been present for a period equal to or longer than the delay, and in case the alarm is enabled, the alarm is provoked.  
 When the alarm is provoked, the signal selected will be activated and the action selected will be taken.  
 The alarm is automatically acknowledged in case auto ack. is enabled.

2022-09-30-09:47:33

The alarm trigger is set up in the EClodic Builder/Linker using the addresses below.

29068	EClodic Alarms01..04	16 unsigned int	bitwise
-------	----------------------	-----------------	---------

## General purpose timers

General purpose timers enable you to trigger your own custom made timer. Via the EClodic Builder/Linker the trigger for the timer to be set up. A total of 8 such timers are available.

### ECLogic timers

Timer 1:	5.0 s
Timer 2:	5.0 s
Timer 3:	5.0 s
Timer 4:	5.0 s
Timer 5:	5.0 s
Timer 6:	5.0 s
Timer 7:	5.0 s
Timer 8	5.0 s



ECLogic timer setup page.  
 The commands for starting the timers are set from ECLogic.  
 The timer elapsed status is available in modbus  
 and can be used as in ECLogic.

2022-10-11-14:52:37

The timer triggers is set up in the ECLogic builder/Linker using the addresses below:


29069	ECLogic Timers 01..08	16 unsigned int	bitwise
-------	-----------------------	-----------------	---------

The output of the timers when they are elapsed are found on the addresses below:

31016	BITFIELD_17	16 unsigned int	ECLogic Timers elapsed 01..16
-------	-------------	-----------------	-------------------------------

## Monitoring

The ECweb provides a high level overview of the installation as well as detailed information about each individual inverter and power meter. Below is an example of the first page presented under the Monitoring tile.



In case genset, PV or utility symbol is grayed out it means that no configuration for sensing of the associated power is made and therefore the source is interpreted as not being present by the ECpvh. The accumulated powers of the three sources as well as total consumptions are displayed.

In case the genset symbol is neither gray nor green it means that all genset breakers are off. In case the genset symbol is green it means that at least one genset breaker is on.

In case the utility symbol is neither gray nor green it means that all mains breakers are off. In case the utility symbol is green it means that at least one mains breaker is on.

In case the PV symbol is neither gray nor green it means that the start signal is not present. In case the PV symbol is green it means that the start signal is present.

In case the PV start button has a vertical line it means that the stop signal is present and the button can be clicked to start the PV plant. In case the PV button has a horizontal line it means that the start signal is present and the button can be clicked to stop the PV plant.

In case the genset start button has a vertical line it means that the stop signal is present and button can be clicked to start the genset plant. In case the genset button has a horizontal line it means that the start signal is present and the button can be clicked to stop the genset plant. Note that this button is only visible in case Genset management functionality is enabled.

Blue and orange arrows indicate active power and reactive power flow direction respectively.

On the left hand side of the sources two blue bar graphs are shown. The one to the left shows the active power loading of the source in percentage. The one to the right shows the deviation from the active power reference in percentage.


On the right hand side of the sources two orange bar graphs are shown. The one to the left shows the reactive power loading of the source in percentage. The one to the right shows the deviation from the reactive power reference in percentage.

In the upper right corner two buttons are shown.

1. Sensor data.
2. IO module data.


## Command panel

Clicking the command panel button will lead to the page below where the button commands and status indications are displayed.



## Sensor data

Clicking the sensor button will lead to the below page where an overview of all the meteorological readings is provided. In case a reading is not supported or communication to the sensor or inverter providing the reading is failing, the readings will be displayed as "N.A".




**Measurement**

POA:	1000 W/m2	RH:	N.A	Fuel level 01:	45.6 %
GHI:	N.A	Bar. press.:	N.A	Fuel level 02:	N.A
BOM:	25.0 C	Wind speed:	N.A	Fuel level 03:	N.A
Amb. temp.:	N.A	Wind dir.:	N.A	Fuel level 04:	N.A
		Rain:	N.A		

2022-03-14-12:06:47

Clicking the up/down navigation buttons will lead to the page below which is displaying the fuel level data.



**Measurement**

Fuel pressure 01:	N.A	Fuel level 01:	45.6 %
Fuel pressure 02:	N.A	Fuel level 02:	N.A
Fuel pressure 03:	N.A	Fuel level 03:	N.A
Fuel pressure 04:	N.A	Fuel level 04:	N.A

2022-04-06-10:41:21

Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various sensor and inverter models: <http://www.encombi.com/products/ECpvh/>

## IO module data


Clicking the IO module button will lead to the below page where an overview of all the readings from the IO modules is provided. In case a reading is not supported or communication to the IO module is failing, the readings will be displayed as "N.A".

IO modules	IO type	IO inputs	IO outputs	Communication state:	Communication enable:
IO 1:	EX1600DD	0000 0000 0000 1000	N.A	Communication state:	Communication enable:
IO 2:	EX1608DD	0000 0000 0001 0000	0000 0000 0000 0000	Communication state:	Communication enable:
IO 3:	OFF	N.A	N.A	Communication state: N.A	Communication enable: N.A
IO 4:	OFF	N.A	N.A	Communication state: N.A	Communication enable: N.A

2020-08-18-11:18:25

## Simulation

In case simulation is enabled it will be indicated as a watermark.



2022-06-28-11:35:08

Furthermore an additional button appears in the upper right corner which. Clicking this button will open the Stimuli page below.

ENcombi
ADMIN

---

**Stimuli**

P load: 100.0 kW


Q load: 10.0 kVAr

Grid freq: 50.0 Hz

Grid volt: 400.0 V

POA: 1000.0 W/m2


BOM: 25.0 C

MB on: 
 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16  


GB on: 
 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16  


Stimuli setup page.

Here the various stimuli like active and reactive loads can be applied.  
 Run thru the various control schemes and see their behaviour.  
 Check out how data on plant level to component level is visualised.  
 Click directly on the data to alter it.  
 Push breaker buttons down to simulate that respective breaker is closed.



2020-07-10-14:11:29




On this page various stimuli can be applied. The changes made take effect when the window is closed. Closing the window will lead back to the monitoring page.




## PV

Clicking the PV icon leads to the below pages where more detailed information of the PV plant can be found. Clicking the up/down arrows will browse through them.

ENcombi
ADMIN

---

**References**

GC: 200.0 kW

PTAR: 70.0 kW

PREF: 70.0 kW

QTAR: 0.0 kVAr

QREF: 0.0 kVAr

CURTAILMENT: ACTIVE

**Production**


ACP: 70.0 kW

ACQ: 0.0 kVAr

ACS: 70.0 kVA

Cosphi: 1.000 C

2021-01-05-15:39:29



### Produced

ACE: 9 kWh  
 ACE YEAR: 9 kWh  
 ACE MONTH: 9 kWh  
 ACE DAY: 9 kWh

### Available

DCE: 16 kWh  
 DCE YEAR: 16 kWh  
 DCE MONTH: 16 kWh  
 DCE DAY: 16 kWh

### Curtailed

DCE: 8 kWh  
 DCE YEAR: 8 kWh  
 DCE MONTH: 8 kWh  
 DCE DAY: 8 kWh

### Imported

ACE: 0 kWh  
 ACE YEAR: 0 kWh  
 ACE MONTH: 0 kWh  
 ACE DAY: 0 kWh


### Performance

PERF: 100.0 %  
 PERF YEAR: 100.0 %  
 PERF MONTH: 100.0 %  
 PERF DAY: 100.0 %

### Penetration

PEN: 35.8 %  
 PEN YEAR: 35.8 %  
 PEN MONTH: 35.8 %  
 PEN DAY: 35.8 %

2021-04-27-10:33:36




### PV export save

Total: 138 Euro  
 Year: 138 Euro  
 Month: 138 Euro  
 Day: 83 Euro

### Mains imp. save

Total: 15 Euro  
 Year: 15 Euro  
 Month: 15 Euro  
 Day: 9 Euro

2021-01-05-15:40:17



### Fuel save

Total: 82 liter  
 Year: 82 liter  
 Month: 82 liter  
 Day: 1 liter


### Fuel exp. save

Total: 46 Euro  
 Year: 46 Euro  
 Month: 46 Euro  
 Day: 1 Euro

### CO2 emiss. save

Total: 217 kg  
 Year: 217 kg  
 Month: 217 kg  
 Day: 3 kg

2021-01-05-15:40:59



**Battery produced**

Total: 4 kWh  
 Year: 4 kWh  
 Month: 4 kWh  
 Day: 4 kWh

**UPS load**

Total: 5 kWh  
 Year: 5 kWh  
 Month: 5 kWh  
 Day: 5 kWh

**Battery imported**

Total: 1 kWh  
 Year: 1 kWh  
 Month: 1 kWh  
 Day: 1 kWh

**PV produced**

Total: 8 kWh  
 Year: 8 kWh  
 Month: 8 kWh  
 Day: 8 kWh

2021-04-27-10:34:22

On the right hand side of the above pages two buttons are presented that will lead to pages with more information about.

1. PV meter data.
2. Inverter data.

### PV meter data


Clicking the meter icon will lead to the below page where overview of power and reactive power readings from all PV meters is provided. In the example below, only one PV meter is present. In case communication to a PV meter is failing, the readings will be displayed as "N.A".



PV	P	Q	PV	P	Q
Meter 1	20.0 kW	0.0 kVAr			



2020-07-10-14:13:40

Clicking on a PV meter label, "Meter1" being the only option in the above example, will lead to a page with more detailed information about that specific PV meter.

Identifiers:		Power factors		Voltages	
Meter 1		PF 1:	1.0	L1N:	230.9 V
Comm ID:	ID2	PF 2:	1.0	L2N:	230.9 V
		PF 3:	1.0	L3N:	230.9 V
		PF:	1.0	L1L2:	400.0 V
<b>Powers</b>		<b>Currents</b>		L2L3:	400.0 V
ACP 1:	6.666 kW	L1A:	28.868 A	L3L1:	400.0 V
ACP 2:	6.666 kW	L2A:	28.868 A	<b>Frequencies</b>	
ACP 3:	6.666 kW	L3A:	28.868 A	HZ 1:	50.0 Hz
ACP:	20.0 kW	LNA:	0.0 A	HZ 2:	50.0 Hz
ACQ 1:	0.0 kVAr	<b>Produced</b>		HZ 3:	50.0 Hz
ACQ 2:	0.0 kVAr	ACE:	N.A.	<b>Status</b>	
ACQ 3:	0.0 kVAr	ACE IMP:	N.A.	Inputs:	0000 0000 0000 0000
ACQ:	0.0 kVAr	ACE EXP:	N.A.		
ACS 1:	6.666 kVA	ACRE:	N.A.		
ACS 2:	6.666 kVA	ACRE IND:	N.A.		
ACS 3:	6.666 kVA	ACRE CAP:	N.A.		
ACS:	20.0 kVA				

Communication state:   
 Communication enable: 

2020-07-10-14:13:57

In the upper left corner the label of the meter can be changed. In the lower right corner communication status for the specific PV meter is shown. In case the PV meter is failing to communicate for whatever reason, communication to that specific meter can be disabled and enabled again at a later state on the start/stop button.

Not all data shown is read/displayed from all meter models supported and will in that case show "N.A". Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various meter models.

<http://www.encombi.com/products/ECpvh/>


### Inverter data

Clicking the inverter icon will lead to the page below where overview of power, reactive power etc. readings from all inverters is provided. In case communication to an inverter is failing, the readings will be displayed as "N.A". Clicking the up/down arrows will browse through them.

Inverter	P	Q	Inverter	P	Q
Inverter 1	20.0 kW	1.0 kVAr			
Inverter 2	20.0 kW	1.0 kVAr			

2021-04-27-11:10:57

Inverter	UPS P	PV P	Battery P	Inverter	UPS P	PV P	Battery P
Inverter 1	20.0 kW	10.8 kW	20.0 kW				
Inverter 2	20.0 kW	21.6 kW	20.0 kW				



2021-04-27-11:11:22

Clicking on an inverter label will lead to pages with more detailed information about that specific inverter. Clicking the up/down arrows will browse through them.

Identifiers:	AC	DC
<b>Inverter 2</b>	L1N: 254.1 V	DCA1: 254.6 A
Serial: GoodWe ET	L2N: 231.2 V	DCU1: 724.5 V
Model: Model12	L3N: 235.2 V	DCP1: 2.5 kW
Version: 1.00.0	L1L2: N.A.	DCA2: 265.4 A
Comm ID: 192.168.1.119, ID:1	L2L3: N.A.	DCU2: 725.4 V
	L3L1: N.A.	DCP2: 2.8 kW
<b>Production</b>	L1A: 14.5 A	DCA3: 457.8 A
ACP: 20.0 kW	L2A: 15.6 A	DCU3: 785.4 V
ACQ: 1.0 kVAh	L3A: 21.4 A	DCP3: 3.1 kW
ACS: 3.0 kVA	HZ: 50.21 Hz	DCA4: 254.6 A
PF: N.A.		DCU4: 758.9 V
		DCP4: 2.4 kW
<b>Produced</b>	<b>Status</b>	
ACE: 4000 kWh	CAB TEMP: N.A.	
ACE DAY: 300.0 kWh	STATE: 0	
OPE: N.A.	EVT1: 0	
OPE DAY: N.A.	EVT2: N.A.	
	EVT3: N.A.	
	EVT4: N.A.	



Communication state:

Communication enable:

2021-04-27-10:35:49

Condition	UPS Voltage	Battery
SOC: 15.0	L1N: N.A.	Battery Temp: N.A.
SOH: 40.0	L2N: N.A.	STATE: N.A.
SOE: N.A.	L3N: N.A.	
	<b>UPS load</b>	<b>DC Battery</b>
	Total: 100 kWh	DCA1: 454.5 A
	Day: 400.0 kWh	DCU1: 745.2 V
	ACP: 20.0 kW	DCP1: 20.0 kW
	DCP1: N.A.	<b>Produced Battery</b>
	DCP2: N.A.	Total: 400 kWh
	DCP3: N.A.	Day: 333.3 kWh
		<b>Imported Battery</b>
		Total: 500 kWh
		Day: 525.2 kWh



Communication state:

Communication enable:

2021-04-27-10:38:35

In the upper left corner on the first page, the label of the inverter can be changed. In the lower right corner communication status for the specific inverter is shown. In case the inverter is failing to communicate for whatever reason, communication to that specific inverter can be disabled and enabled again at a later state on the start/stop button.

Not all data shown is read/displayed from all inverter models supported and will in that case show "N.A". Consult the Modbus master documentation on ENcombi website for detailed information about what data is read from the various inverter models.

<http://www.encombi.com/products/ECpvh/>

## Genset

Clicking the genset icon leads to the below page where more detailed information of the genset plant can be found.

ENcombi

ADMIN



### Production

ACP: 30.0 kW  
 ACQ: 10.0 kVA  
 ACS: 31.6 kVA  
 Cosphi: 0.948 C

### LOADING:

GC: 100.0 kW  
 LOADING: 30.0 %  
 PTAR: 30.0 %

### Fuel consumed

Total: 2262 liter  
 Year: 2262 liter  
 Month: 2262 liter  
 Day: 1 liter

### Fuel expense

Total: 2784 Euro  
 Year: 2784 Euro  
 Month: 2784 Euro  
 Day: 1 Euro

### Produced

ACE: 8844 kWh  
 ACE YEAR: 8844 kWh  
 ACE MONTH: 8844 kWh  
 ACE DAY: 2 kWh

### CO2 emission

Total: 5973 kg  
 Year: 5973 kg  
 Month: 5973 kg  
 Day: 1 kg

2021-01-05-15:41:54

On the right hand side of the above pages a button is presented that will lead to pages with more information about genset meters.

## Genset meter data

Clicking the meter icon will lead to similar pages holding genset meter data as already documented previously for PV meters. Refer to that chapter for more information.

## Mains

Clicking the utility icon leads to the below page where more detailed information of the utility can be found.



**Production**

ACP: 50.0 kW  
 ACQ: 10.0 kVAr  
 ACS: 51.0 kVA  
 Cosphi: 0.980 C

**Imported**

ACE: 123 kWh  
 ACE YEAR: 123 kWh  
 ACE MONTH: 123 kWh  
 ACE DAY: 5 kWh  
 Total: 3 Euro  
 Year: 3 Euro  
 Month: 3 Euro  
 Day: 0 Euro

**Exported**

ACE: 0 kWh  
 ACE YEAR: 0 kWh  
 ACE MONTH: 0 kWh  
 ACE DAY: 0 kWh  
 Total: 0 Euro  
 Year: 0 Euro  
 Month: 0 Euro  
 Day: 0 Euro

2021-01-05-15:48:19

On the right hand side of the above pages a button is presented that will lead to pages with more information about mains meters.


## Mains meter data

Clicking the meter icon will lead to similar pages holding mains meter data as already documented previously for PV meters. Refer to that chapter for more information.

## Spot price market data

Clicking the spot price button will lead to the page below where the hourly spot prices can be seen.

Spot price



2023-09-18-08:33:14

## Load

Clicking the load icon leads to the below page where more detailed information of the load can be found.



**Consumption**


ACP: 100.0 kW  
 ACQ: 10.0 kVA<sub>r</sub>  
 ACS: 100.5 kVA  
 Cosp<sub>hi</sub>: 0.995 C


**Consumed**

ACE: 9 kWh  
 ACE YEAR: 9 kWh  
 ACE MONTH: 9 kWh  
 ACE DAY: 9 kWh

## ECpvh as power meter

An ECpvh can serve as a power meter(s) to another ECpvh. This means that one ECpvh can read the power meter data, via either Modbus RTU or Modbus TCP, polled by another ECpvh. This is useful in cases like the below examples where two PV plants are present in the same system. Both examples show inverters controlled via Modbus TCP but it could just as well have been Modbus RTU.





In the examples ECpvh\_1 is reading the data from the power meters via Modbus RTU. ECpvh\_2 is getting the same information but it is reading it via Modbus TCP from ECpvh\_1.

This is a very useful feature as both ECpvhs requires the information from power meters and you would otherwise need to install an additional component in the shape of a Modbus RTU Multiplexer to allow both ECpvhs to act as Modbus Masters towards the power meters and read out the data.

It is configured in the same manner as described in the previous chapter of power meter configuration. Below is an example with genset meter configuration.

ENcombi
ADMIN

---

<b>Genset</b>			
Power meter:	ENCOMBI ECPV	<p><b>Genset power meter setup page.</b>            A maximum of 16 power meters for gensets is supported.            The same make/model must be used for all genset measurements.            The communication can be either Modbus RTU or TCP.</p> <p>The Modbus IDs of the meters must be sequential            in case of RTU, with lowest ID being equal to the            setting made in the device.</p> <p>The IP addresses of the meters must be sequential,            in case of TCP, with lowest IP address being equal to the            setting made in the device.            The Modbus ID selected is used in the TCP frames.</p> <p>Port settings is setup on dedicated port setup page.</p>	
Modbus type:	TCP		
ID:	1		
IP:	192.168.1.79		
Number:	2		


2020-07-10-14:38:10

Note that the ECpvh will be reading data of multiple power meters from a single ECpvh. In the above configuration the ECpvh will be reading data from two genset power meters from an ECpvh having IP address 192.168.1.79.

## ECpvH stacking

### Inverter stacking

A single ECpvH can control and monitor a maximum of 32 inverters all which must be from the same vendor and possibly of the same model. If to control more than 32 inverters or a mix of inverter makes/models multiple ECpvH's can be stacked and worked together as illustrated in the schematic below.



In the above example three clusters of inverters are present. These clusters can each contain up to 32 inverters and can be of another make/model than the inverters used in the other inverter clusters.

### ECpvH slave

Each cluster is controlled by a slave ECpvH. That can be via Modbus RTU as in the above example or it can be via Modbus TCP.

For PV reference under the Settings tile, these three ECpvH will be configured as being SunSpec slaves.

**References**

Priority:	OFF
Cosphi cap:	0.600 C
Cosphi ind:	0.600 I
Cosphi lim:	DISABLED
Proprietary slave:	ENABLED
SunSpec slave:	DISABLED
Sensing method:	SUM ALL PHASES
<b>Measurement</b>	
kW Origin:	PV METER
kWh Origin:	ECPV



PV reference setup page.

Priority setting determines whether to prioritise P or Q reference over the other in case exceeding rated S inverter capacity.

Cosphi cap and Cosphi ind outlines operating range of the inverters. In case enabled and reference exceeding, the device will limit the Q reference.

In case Proprietary slave is enabled, the device will accept references received from a Modbus master.

In case SunSpec slave is enabled, the device will accept references received from a SunSpec master.

Sensing method determines if to base reference on the sum of all phases or 3 x sensing values.

AC origin determines from which source the PV production arises.

kWh origin determines from which source the genset energy production arises.



2021-01-06-15:52:02

The inverter protocol itself to select in the ECpvH slaves is determined by the make/model of inverters inside their respective inverter clusters.

## ECpvH Master


The fourth ECpvH will act as a normal ECpvH which interacts with the gensets and utility connections.

It will see the three ECpvH slaves simply as three (big) inverters running SunSpec, being ignorant to the fact that it is actually three clusters of inverters. Therefore the inverter protocol to select in the master ECpvH must be SunSpec. The connection to the ECpvH slaves can be Modbus TCP as in the above example or it can be Modbus RTU.

As an ECpvH can control up to 32 inverters, the maximum capacity of an ECpvH master will be 32 inverter clusters. Should this not be sufficient yet another ECpvH master can be applied on top of up to 32 ECpvH masters and so on.

## Genset stacking

A single ECpvH can monitor a maximum of 16 genset power meters all which must be from the same vendor and possibly of the same model. If to monitor more than 16 genset power meters or a mix of makers/models multiple ECpvH's can be stacked and worked together as illustrated in the schematic below.



In the above example two Groups of gensets are present. These groups can each contain up to 16 genset power meters and can be of another make/model than the power meters used in the other genset groups.

### ECpvH slave

Each group is controlled by a slave ECpvH. That can be via Modbus TCP as in the above example or it can be via Modbus RTU.

The genset power meter protocol itself to select in the ECpvH slaves is determined by the make/model of power meters inside their respective group.

### ECpvH Master

The third ECpvH will act as a normal ECpvH which interacts with the gensets and other connections.

It will see the two ECpvH slaves simply as two (big) gensets, being ignorant to the fact that it is actually two groups of gensets. Therefore the genset power meter protocol to select in the master ECpvH must be "ENcombi DG Group". The connection to the ECpvH slaves can be Modbus TCP as in the above example or it can be Modbus RTU.

As an ECpvH can control up to 16 genset power meters, the maximum capacity of an ECpvH master will be 16 genset groups. Should this not be sufficient yet another ECpvH master can be applied on top of up to 16 ECpvH masters and so on.


## Service Tool

First page to be displayed after an initial welcome page when switching to the Service Tool application is the front page of ECweb.

ENcombi



Select your category



2020-07-26-10:57:51

Navigating around in the Service Tool is done in the same manner as in the ECpvh application.

In the lower center two menu tiles are available. These are from the left:

1. "Identifiers" gives access to overview of SW version installed as well as to the menu for switching between the applications.
2. "Settings" give access to the set up of various features.

In the following chapters the content of the two menu tiles are discussed in detail.

## Identifiers

Under this tile overview of SW version installed and extras present in the ECpvh as well as to the menu for switching between the applications.

### ENcombi

**Company:**

Name:	Website:	Contact:	Support:	Cloud service:
ENcombi	www.encombi.com	sales@encombi.com	support@encombi.com	www.encombi.online



**Product:**

Type:	Extras:	Project version:	Serial number:
ECpvh Service Tool	-C-L-	1.00.0	202104230002

**Platform:**

Device type:	Device variant:	Chip type:	Rtos:	Version:
WP240X	COM	SC24	V2.07 FULL	V23.9.63.1

**Identifiers:**

Serial number 1:	Serial number 2:	MAC address:
F7D9CD475FC3B4ED	2EDC5B18730B0982	003056914972

2021-04-27-13:24:00

On the right hand side there are one submenu for.

1. Application switch.

## Application

Clicking the Application button leads to the page below. Here it can be selected which application is to be active.

### ENcombi

ADMIN

**Application**

Application: ECPVH



**Application swap page.**  
 Here it is set up which application to run.  
 When toggling between applications, the device is to be reboot. Any settings made in the ECpv application will be lost in the process. Store a backup before leaving the ECpv project if any settings are made that is to be restored when reverting to the ECpv application. Browser needs refreshing when the device has rebooted.

2021-04-27-12:21:15

The following applications are available.

1. ECpvh.

2. ECpvh Service Tool.
3. ECpvh Boot.

ECpvh is the default application and the one to use for the normal operation of the ECpvh. ECpvh Service Tool is a separate application that offers various tests and configurations features and the ECpvh Boot is a tool for updating both the ECpvh and the ECpvh Service Tool SW.

When toggling between applications the device is to be rebooted. Any settings made in the ECpvh application will be lost in the process. Make a backup before leaving the ECpvh application if any settings are made that are to be restored when reverting to the ECpvh application once again. The browser needs refreshing when the device is rebooted after switching the application.

## Settings

Under this tile the setup of various features are found.

First page presented when clicking the Settings tile is the below page where COM2 configuration is set up.

### ENcombi

#### COM2 port

Baudrate:	19200
Parity:	NO PARITY 1 STOP BIT
Timeout:	1.0 s
TX rate:	1.0 s
Slave ID:	1



COM2 Port setup page.  
Baudrates supported are 9600, 19200, 38400 and 115200.

Power meter RTU communication is fixed on COM2.  
Sensor RTU communication is optional on COM2.  
In case none of these communications are enabled, COM2 is serving as a Modbus RTU slave.

Slave ID is only used in case COM2 is serving as a slave.



2020-07-31-13:15:20

Baud rates supported are:

- 9600, 19200, 38400 and 115200

Parity supported are:

- "Parity one stop bit", "No parity", "Even parity" and "Odd parity".

On the same menu level a similar setup page for COM3 configuration is found. Clicking the up/down arrows will lead to it.

On the right hand side there are two submenus for.

1. Power meter configuration.
2. Modbus Tester.
3. Client Trace.

### Power meter configuration

Power meter configuration allows you to read and write the configurations of various power meters over Modbus. Clicking the Power meter button leads to the page below where a Pilot SPM32 power meter can be configured.

**SPM32 config**

Baudrate:	9600
CT ratio:	1
VT ratio:	1
Conn mode:	3 Phase 4 Wire
Modbus ID:	1

SPM32 setup page.  
 Here a SPM32 power meter can be set up.  
 It is fixed to use COM2.  
 Port settings is setup at dedicated port setup page.  
 Connect A(-) on the ECpv to RS485+ on the SPM32 and  
 Connect B(+) on the ECpv to RS485- on the SPM32.  
 Note that the SPM32 Modbus ID is set via the  
 dipswitches on the back side.

2020-07-31-13:18:19

Clicking up/down buttons will navigate through all the meter power meter configurators supported. Currently the following are supported:

1. Pilot SPM32.
2. Pilot SPM33.

## IO configuration

IO configuration allows you to read and write the configurations of IO module over Modbus. Clicking the IO button leads to the page below where COM2 or COM3 can be selected.

**IO modules**

COM port:	COM2
-----------	------

IO module setup page.  
 IO module communication can either run Modbus RTU or Modbus TCP.  
 Whether to use COM2, COM3 or TCP is selectable by parameter.  
 Port settings is setup at dedicated port setup page.

2021-09-20-14:29:30




Afterwards clicking on the IO configuration button on the right hand side leads to the IO configuration page.

## ENcombi

## IO module comm.

Baudrate:	9600
Parity:	EVEN PARITY
Modbus ID:	-
Timeout:	-

## IO module search

Modbus ID:	<input type="text" value="1"/>	  
Module:	N.A.	
FW version:	N.A.	



## Overdigit IO module communication setup page.

After IO module is powered up, then press the PG button on the IO module for 3s until the green LED starts flashing. Now the IO module is in a temporary state having the Baudrate and Parity listed in the colored Active Column. Note that the COM port selected for IO module communication must be configured accordingly to complete the configuration successfully. In the update column the requested communication setup is made and Save button is pushed to write it to the IO module. Afterwards, press the PG button again to stop the green LED flashing and activate the communication setup just made.

The Timeout determines the delay for no communication being active before the IO module releases all its relays. Setting it to "0 x 10ms" means disabling the functionality and the IO module will keep the relays at there states in case of communication loss.

Search a Modbus ID to find module type and firmware version.

2022-02-07-14:32:39

It is possible to set up the Overdigit IO module with the tool.

After the IO module is powered up, then press the PG button on the IO module for 3s until the green LED starts flashing. Now the IO module is in a temporary state having the Baudrate and Parity listed in the colored Active Column. Note that the COM port selected for IO module communication must be configured accordingly to complete the configuration successfully. In the update column the requested communication setup is made and the Save button is pushed to write it to the IO module. Afterwards, press the PG button again to stop the green LED flashing and activate the communication setup just made.

The Timeout determines the delay for no communication being active before the IO module releases all its relays. Setting it to "0 x 10ms" means disabling the functionality and the IO module will keep the relays at their states in case of communication loss.

## AIO

When pressing the settings icon, it will lead to the following page.

### ENcombi

#### EX04AIO config

Channel 1 type: OFF

Channel 1 source: 0-10V

Channel 2 type: OFF

Channel 2 source: 0-10V

Channel 3 type: OFF

Channel 3 source: 0-10V

Channel 4 type: OFF

Channel 4 source: 0-10V

Modbus ID: -



Overdigit AIO module communication setup page.  
Here an EX04AIO can be set up.  
It is optional which port to use. It is setup at dedicated COM page.  
Port settings is setup at dedicated port setup page.

Setup input and output for all 4 channels.  
Modbus ID needs to be set in order to write configuration.

2022-02-07-14:34:29

From there it is possible to set up an EX04AIO module. From here it is selectable which channel to use for input and output.

All 4 channels can be selected as off, input and output. It is also selectable which source the input or output should work with. The two options are 0-10 or 4-20mA.

When the configuration is ready, the modbus ID must be set and after that it is possible to write the configuration to the module. An icon will show if the writing was successful or failed.

Toggle to the next page will lead to the set up of EX04AIS.

### ENcombi

#### EX04AIS config

Channel 1 source: OFF

Channel 2 source: OFF

Channel 3 source: OFF

Channel 4 source: OFF

Modbus ID: -



Overdigit AIS module communication setup page.  
Here an EX04AIS can be set up.  
It is optional which port to use. It is setup at dedicated COM page.  
Port settings is setup at dedicated port setup page.

Setup input for all 4 channels.  
Modbus ID needs to be set in order to write configuration.

2022-02-08-09:42:21

This is only inputs, so the only configuration is which source the channels should be. It can also be selected as OFF, which means the channel is deactivated.

## Sensor Configuration

The Sensor configuration allows you to read and write the configurations of various sensors over Modbus. Clicking the Sensor button leads to the page below where it is set up whether the Sensor configuration is to use COM2 or COM3.

### ENcombi

Sensors

COM port: COM2



Sensor setup page.  
Sensor communication is running Modbus RTU only.  
Whether to use COM2 or COM3 is selectable by parameter.  
Port settings is setup at dedicated port setup page.



2022-03-11-15-07:41

Afterwards clicking on the setup button on the right hand side leads to the Sensor configuration itself where the Sensor modules communication settings can be adjusted and the Sensor modules can be searched and identified.

### ENcombi

SolSolare config

Baudrate:

N.A.

Parity:

N.A.

Modbus ID:

N.A.

60

Serial:

N.A.

FW main:

N.A.

FW minor:

N.A.



Soluzione Solare setup page.  
Here the Soluzione Solare sensors can be set up.  
Port settings are setup at dedicated port setup pages.  
Connect A(-) on the ECpv to RS485+/B on the sensor and  
Connect B(+) on the ECpv to RS485-/A on the sensor.



2022-03-11-15-08:02

## Modbus Tester

Modbus Tester is a feature where the Service Tool acts as a Modbus RTU Master and communication with a Modbus RTU Slave can be tested. Clicking the Modbus Tester button leads to the page below where it is set up whether the Modbus Tester is to use COM2 or COM3.

### Modbus tester

COM port: COM2



Modbus test page.  
Here read and write commands can be tested.  
The Modbus tester is for Modbus RTU only.  
Whether to use COM2 or COM3 is selectable by parameter.  
Port settings is setup at dedicated port setup page.



2020-07-26-11:17:56

Afterwards clicking on the Modbus Tester button on the right hand side leads to the Modbus Tester itself where Modbus RTU read and write commands of various length and function codes can be transmitted and the response received is shown.

**Read**

Start ID:	Stop ID:	Control Fnc:	Control Fnc:	Control Fnc:	Address:	Length:	
1	1	0x03	16BIT	SIGNED	0	1	
N.A	N.A	N.A	N.A	N.A	1	N.A	
N.A	N.A	N.A	N.A	N.A	N.A		
Register 1..2	Register 3..4	Register 5..6	Register 7..8	Register 9..10	Byte 01..20		

**Write**

Modbus ID:	Control Fnc:	Control Fnc:	Control Fnc:	Address:	Command:	
1	0x06	16BIT	SIGNED	0	0	
UNICAST	N.A					

2022-03-11-14:56:43



## Client trace

Clicking the Client Trace button leads to the page below where trace of Modbus communication can be enabled/disabled. The Modbus Tester only shows the result/content of valid Modbus frames received. The Trace on the other hand provides information on any communication being detected on the RS485 line event though if it is not perceived as valid Modbus frames.

### ENcombi

**Trace**

Modbus:                   DISABLED

Trace setup page.  
Enabling/disabling trace of various device client activities.  
Trace is readable via device Telnet server.

---

2020-07-26-11:35:57

The Trace is available via the built in Telnet server. Clicking on the Telnet server button on the right hand side leads to the Telnet server setup.

## Telnet server

On the page below the telnet server access is set up.



### ENcombi

**TELNET Server:**

User0:                   telnet\_user0

Password0:               \*\*\*\*\*

Telnet:                   ENABLED

ADMIN



Telnet server setup page.  
Credential is for device telnet server access.  
Telnet is usable for tracing various device client activities.

---

2020-07-10-13:14:30

Use the PC application "Chiptool" to connect to the Telnet Server to follow activities such as the Modbus trace.

## Boot

First page to be displayed after an initial welcome page when switching to the Boot application is the front page of ECweb.

ENcombi



Select your category



---

2021-02-02-13:42:34

Navigating around in the Service Tool is done in the same manner as in the ECpvh application.

In the lower center one menu tile is available:

1. "Identifiers" gives access to overview of SW version as well as to the menus for updating SW and switching between the applications.

In the following chapters the content of the menu tile is discussed in detail.

## Identifiers

Under this tile overview of SW version installed and extras present in the ECpvh.

### ENcombi

**Company:**

Name:	Website:	Contact:	Support:	Cloud service:
ENcombi	www.encombi.com	sales@encombi.com	support@encombi.com	www.encombi.online



**Product:**

Type:	Extras:	Project version:	Serial number:
ECpv Boot	-C-H-L-	1.00.0	201901030001

**Platform:**

Device type:	Device variant:	Chip type:	Rtos:	Version:
WP240	COM	SC24L	V2.06 FULL	V23.9.62.2

**Identifiers:**

Serial number 1:	Serial number 2:	MAC address:
DF7BC72FA92129E4	5E8BF28E33F0FABB	0030569108A2

2021-02-02-13:43:01

On the right hand side there are one submenu for.

1. SW update.
2. Application switch.

## SW update

Clicking the SW update button leads to the page below. From here the ECpvh and the ECpvh Service Tool SW can be updated from a USB stick.

### ENcombi




Device project update via USB.

- 1: Create an empty folder on your laptop named ECpv\_SW.
- 1: Download the SW file from the website.
- 2: Unzip the downloaded file.
- 3: Navigate to the SW version folder.
- 4: Copy the content of the SW version folder.
- 5: Paste the content to the ECpv\_SW folder.
- 6: Copy the ECpv\_SW folder to the root of a USB stick.
- 7: Insert USB stick into the device.
- 8: Click the search for SW button.
- 9: Wait for the process to complete.
- 10: If completed successfully then revert to the ECPV application.



2021-02-16-16:07:06

Download the SW from the website and place it in a folder named "ECpvh\_SW" in the root of a USB stick like shown below:



Then insert the USB stick into the ECpvh and press the binoculars button to start the SW update. When SW update is completed successfully, then you can safely revert to the ECpvh application. If the SW is interrupted and it fails, then remain in the Boot application and try to update the SW once again. Do not return to the ECpvh application until SW update is completed successfully.

## Application

Clicking the Application button leads to the page below. Here it can be selected which application is to be active.

ENcombi ADMIN

Application

Application: ECPVH

Application swap page.  
Here it is set up which application to run.  
When toggling between applications, the device  
is to be reboot. Any settings made in the ECpv application  
will be lost in the process. Store a backup before leaving  
the ECpv project if any settings are made that is to be  
restored when reverting to the ECpv application.  
Browser needs refreshing when the device has rebooted.

2021-04-27-12:21:15

The following applications are available.

1. ECpvh.
2. ECpvh Service Tool.
3. ECpvh Boot.

ECpvh is the default application and the one to use for the normal operation of the ECpvh. ECpvh Service Tool is a separate application that offers various tests and configurations features and the ECpvh Boot is a tool for updating both the ECpvh and the ECpvh Service Tool SW.

When toggling between applications the device is to be rebooted. Any settings made in the ECpvh application will be lost in the process. Make a backup before leaving the ECpvh application if any settings are made that are to be restored when reverting to the ECpvh application once again. The browser needs refreshing when the device is rebooted after switching the application.